

## INSTALLATION INSTRUCTIONS

### Direct Vent (Sealed Combustion) Forced Air

**For Installation in:**

- Manufactured Homes
- Modular Homes / Buildings
- Park Models, & Manufactured Buildings



### **⚠ WARNING**

**FIRE OR EXPLOSION HAZARD**

- Failure to follow safety warnings exactly could result in serious injury or property damage.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

**WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a neighbors phone. Follow the gas suppliers instructions.
- If you cannot reach your gas supplier, call the fire department.

### **⚠ AVERTISSEMENT**

**RISQUE D'INCENDIE OU D'EXPLOSION**

- Le non-respect des avertissements de sécurité pourrait entraîner des blessures graves ou des dommages matériels.
- L'installation et l'entretien doivent être effectués par un installateur qualifié, un organisme de service ou le fournisseur de gaz.
- Ne pas entreposer ni utiliser de l'essence ni d'autres vapeurs ou liquides inflammables dans le voisinage de cet appareil, ni de tout autre appareil.

**QUE FAIRE S'IL Y A UNE ODEUR DE GAZ**

- Ne tenter d'allumer aucun appareil.
- Ne toucher à aucun interrupteur électrique; n'utiliser aucun téléphone dans le bâtiment.
- Évacuer l'immeuble immédiatement.
- Appeler immédiatement le fournisseur de gaz en employant le téléphone d'un voisin. Respecter les instructions du fournisseur de gaz.
- Si personne ne répond, appeler le service des incendies.

**DO NOT DESTROY. PLEASE READ CAREFULLY & KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.  
NE PAS DÉTRUIRE. VEUILLEZ LIRE ATTENTIVEMENT ET CONSERVER EN UN LIEU SÛR POUR RÉFÉRENCE ULTÉRIEURE.**

## TABLE OF CONTENTS

|  |           |  |           |
|--|-----------|--|-----------|
| <b>IMPORTANT SAFETY INFORMATION.....</b>         | <b>3</b>  | <b>ELECTRICAL WIRING .....</b>                       | <b>21</b> |
| <b>REQUIREMENTS &amp; CODES .....</b>            | <b>4</b>  | Line Voltage Wiring .....                            | 21        |
| Clearances to Combustible Materials.....         | 4         | Grounding.....                                       | 21        |
| Combustion Air Quality.....                      | 5         | Thermostat / Low Voltage Connections.....            | 21        |
| Heating Load .....                               | 5         | Heat Anticipator.....                                | 22        |
| Condensate Disposal .....                        | 5         | <b>START-UP &amp; ADJUSTMENTS.....</b>               | <b>23</b> |
| <b>COMBUSTION AIR &amp; VENTING REQUIREMENTS</b> | <b>6</b>  | Pre-Start Check List .....                           | 23        |
| Important Information .....                      | 7         | Start-up Procedures .....                            | 23        |
| Category IV Appliances.....                      | 7         | Verifying & Adjusting Input Rate.....                | 23        |
| Direct Vent Installation.....                    | 7         | Verifying & Adjusting Temperature Rise.....          | 23        |
| Vent Pipe Length & Diameter.....                 | 7         | Verifying Burner Operation .....                     | 24        |
| Vent Pipe Material.....                          | 8         | Verifying Operation of the Supply Air Limit Switch . | 24        |
| Vent Pipe Installation .....                     | 8         | <b>OPERATING SEQUENCE .....</b>                      | <b>25</b> |
| Outdoor Terminations - Horizontal Venting.....   | 8         | Heating Cycle .....                                  | 25        |
| Outdoor Terminations - Vertical Venting .....    | 9         | Cooling Cycle .....                                  | 25        |
| Vent Freezing Protection.....                    | 10        | Fan Mode .....                                       | 25        |
| Existing Installations.....                      | 10        | <b>MAINTENANCE .....</b>                             | <b>25</b> |
| Ventilaire III or IV Air Quality Package .....   | 10        | Air Filter(s).....                                   | 26        |
| <b>CIRCULATING AIR REQUIREMENTS.....</b>         | <b>11</b> | Blower Compartment.....                              | 26        |
| Plenums & Air Ducts.....                         | 11        | Cleaning of Burners.....                             | 26        |
| Supply Air Connections .....                     | 11        | Vent System .....                                    | 26        |
| Dampers.....                                     | 11        | Heat Exchanger & Burner Maintenance.....             | 26        |
| Unconditioned Spaces.....                        | 11        | Lubrication .....                                    | 26        |
| Closet Installations .....                       | 11        | <b>TROUBLESHOOTING .....</b>                         | <b>27</b> |
| Furnace Filter .....                             | 12        | <b>FURNACE COMPONENTS .....</b>                      | <b>27</b> |
| Acoustical Treatments.....                       | 12        | <b>FIGURES &amp; TABLES.....</b>                     | <b>28</b> |
| <b>FURNACE INSTALLATION.....</b>                 | <b>13</b> | Figure 18. Furnace Dimensions .....                  | 28        |
| General Information.....                         | 13        | Electrical Diagrams & Data.....                      | 29        |
| Before You Install this Furnace .....            | 13        | Figure 19. CMF95 Wiring Diagram .....                | 29        |
| Locating the Unit.....                           | 13        | Gas Information .....                                | 30        |
| MA-200 Base Installation.....                    | 13        | Table 7. Gas Flow Rates.....                         | 30        |
| Installing the Furnace on an MA-200 Base .....   | 13        | Table 8. Gas Pipe Capacities.....                    | 30        |
| MA-100 Universal Base Installation.....          | 14        | Table 9. Orifices for Propane Gas.....               | 31        |
| Installing the Furnace on an MA-100 Base .....   | 15        | Table 10. Natural Gas Heating Values.....            | 31        |
| Condensate Drainage.....                         | 15        | Table 11. Orifices for Natural Gas                   | 31        |
| <b>GAS SUPPLY &amp; PIPING.....</b>              | <b>16</b> | High Heating Value .....                             | 31        |
| Leak Check.....                                  | 16        | Table 12. Orifices for Natural Gas                   | 31        |
| High Altitude Application.....                   | 17        | Low Heating Value .....                              | 31        |
| Installation Example .....                       | 18        | Venting Information .....                            | 32        |
| Converting to LP/Propane Gas at Altitudes        | 18        | Table 13. Vent Termination Clearances.....           | 32        |
| between 0 & 10,000 FT. ....                      | 18        | Figure 20. Horizontal & Vertical Venting .....       | 33        |
| Removing The Burner Orifices.....                | 19        | <b>INSTALLATION CHECKLIST.....</b>                   | <b>36</b> |
| Gas Pressure Verification.....                   | 19        |  |           |
| Measuring the Supply Gas Pressure .....          | 19        |  |           |
| Lighting & Adjustment of the Appliance .....     | 20        |  |           |
| Measuring the Manifold Pressure .....            | 20        |  |           |
| Removing the Manometer/Pressure Gauge.....       | 20        |  |           |
| Completing the Conversion .....                  | 20        |  |           |

## IMPORTANT SAFETY INFORMATION

**INSTALLER:** Please read all instructions before servicing this equipment. Pay attention to all safety warnings and any other special notes highlighted in the manual. Safety markings are used frequently throughout this manual to designate a degree or level of seriousness and should not be ignored.

**WARNING** indicates a potentially hazardous situation that if not avoided, could result in personal injury or death.

**CAUTION** indicates a potentially hazardous situation that if not avoided, may result in minor or moderate injury or property damage.

- To minimize equipment failure or personal injury, it is essential that only qualified individuals install, service, or maintain this equipment. If you do not possess mechanical skills or tools, call your local dealer for assistance.
- Follow all precautions in the literature, on tags, and on labels provided with the equipment. Read and thoroughly understand the instructions provided with the equipment prior to performing the installation and operational checkout of the equipment.
- Use caution when handling this appliance or removing components. Personal injury can occur from sharp metal edges present in all sheet metal constructed equipment.
- Do not store any of the following on, or in contact with, the unit: Rags, brooms, vacuum cleaners, or other cleaning tools, spray or aerosol cans, soap powders, bleaches, waxes, cleaning compounds, plastics or plastic containers, paper bags or other paper products, gasoline, kerosene, cigarette lighter fluid, dry cleaning fluids, paint thinners, or other volatile fluids.
- Installation of equipment may require brazing operations. Installer must comply with safety codes and wear appropriate safety equipment (safety glasses, work gloves, fire extinguisher, etc.) when performing brazing operations.
- The installer should become familiar with the units wiring diagram before making any electrical connections to the unit. See the unit wiring label or Figure 19 (page 29).
- Always reinstall the doors on the indoor blower after servicing or cleaning/changing the filters. Do not operate the indoor blower without all doors and covers in place.

---

### **WARNING:**

---

**The safety information listed in this manual must be followed during the installation, service, and operation of this unit. Unqualified individuals should not attempt to interpret these instructions or install this equipment. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.**

---

---

### **WARNING:**

---

#### **ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD**

**Failure to follow safety warnings exactly could result in serious injury or property damage.**

**Improper servicing could result in dangerous operation, serious injury, death or property damage.**

- **Before servicing, disconnect all electrical power to the indoor blower.**
  - **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
  - **Verify proper operation after servicing.**
- 

---

### **WARNING:**

---

#### **FIRE OR EXPLOSION HAZARD**

- **Failure to follow safety warnings exactly could result in serious injury or property damage.**
- **Installation and service must be performed by a qualified installer, service agency or the gas supplier.**
- **Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.**

#### **WHAT TO DO IF YOU SMELL GAS**

- **Do not try to light any appliance.**
  - **Do not touch any electrical switch; do not use any phone in your building.**
  - **Leave the building immediately.**
  - **Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.**
  - **If you cannot reach your gas supplier, call the fire department.**
- 

---

### **WARNING:**

---

**Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage. Unless otherwise noted in these instructions, only factory authorized kits or accessories may be used with this product.**

---

---

### **WARNING:**

---

**Unless otherwise noted in these instructions, only factory authorized kits or accessories may be used with or when modifying this product.**

---

## REQUIREMENTS & CODES

### **WARNING:**

**The information listed below must be followed during the installation, service, and operation of this furnace. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.**

- This furnace must be installed in accordance with these instructions, all applicable local building codes and the current revision of the National Fuel Gas Code (NFPA54/ANSI Z223.1) or the Natural Gas and Propane Installation Code, CAN/CGA B149.1.
- Use only with type of gas approved for this furnace. Refer to the furnace rating plate.
- Install this furnace only in a location and position as specified on page 5.
- Provide adequate combustion and ventilation air to the furnace space as specified on pages 6 - 10.
- Provide adequate clearances around the vent air intake terminal as specified in Figures 1 - 4 (pages 9 - 10).
- Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified on pages 7 - 10.
- Never test for gas leaks with an open flame. Use a commercially available soap solution to check all connections. See pages 16 - 17.
- This furnace is designed to operate with a maximum external pressure rise of 0.3 inches of water column. Consult Table 5 (page 24) and the rating plate for the proper circulating air flow and temperature rise. It is important that the duct system be designed to provide the correct flow rates and external pressure rise. An improperly designed duct system can result in nuisance shutdowns, and comfort or noise issues.
- This furnace must not be used for temporary heating of buildings or structures under construction.
- The Commonwealth of Massachusetts requires compliance with regulation 248 CMR 4.00 and 5.00 for installation of through-the-wall vented gas appliances as follows:
  1. For direct-vent appliances, mechanical-vent heating appliances or domestic hot water equipment, where the bottom of the vent terminal and the air intake is installed below four feet above grade the following requirements must be satisfied:
    - a.) A carbon monoxide (CO) detector and alarm shall be placed on each floor level where there are bedrooms. The detector shall comply with NFPA 720 (2005 Edition) and be mounted in the living area outside the bedroom(s).
    - b.) A (CO) detector shall be located in the room that houses the appliance or equipment and shall:
      - Be powered by the same electrical circuit as the appliance or equipment. Only one service switch shall power the appliance and the (CO) detector;
      - Have battery back-up power;
  2. For direct-vent appliances, mechanical vent heating appliances or domestic hot water equipment where the bottom of the vent terminal and the air intake is installed above four feet above grade the following requirements must be satisfied:
    - a.) A (CO) detector and alarm shall be placed on each floor level where there are bedrooms. The detector shall comply with NFPA 720 (2005 Edition) and be mounted in the living area outside the bedroom(s).
    - b.) The (CO) detector shall:
      - Be located in the room that houses the appliance or equipment;
      - Be hard-wired, battery powered or both.
      - Shall comply with NFPA 720 (2005 Edition).
    - c.) A product-approved vent terminal must be used, and if applicable, a product-approved air intake must be used. Installation shall be in strict compliance with the manufacturer's instructions. A copy of the installation instructions shall remain with the appliance or equipment at the completion of the installation.

### **Clearances to Combustible Materials**

This furnace is Design Certified in the U.S. and Canada by CSA International for the minimum clearances to combustible materials. **NOTE:** The furnace is listed for installation on combustible or non-combustible flooring. However, wood is the only combustible flooring allowed for installation. To obtain furnace base model number and specific clearance information, refer to the furnace rating plate, located inside of the furnace cabinet.

Access for positioning and servicing the unit must be considered when locating unit. The need to provide clearance for access to panels or doors may require clearance distances over and above the requirements. **Allow 18 inches minimum clearance from the front of the unit. However 36 inches is strongly recommended.** See Table 1 for minimum clearance requirements.

The ductwork should be appropriately sized to the capacity of the furnace to ensure its proper airflow rating. For installations above 2,000 ft., the furnace should have a sea level input rating large enough that it will meet the heating load after deration for altitude.

## Combustion Air Quality

### CAUTION:

**Combustion air must not be drawn from a corrosive atmosphere.**

To maximize heat exchanger life, the combustion air must be free of chemicals that can form corrosive acidic compounds in the combustion gases. The required source of combustion air is to use outdoor air.


If outside air is used as return air to the furnace for ventilation or to improve indoor air quality, the system must be designed so that the return air is not less than 60° F (15° C) during operation. If a combination of indoor and outdoor air is used, the ducts and damper system must

be designed so that the return air supply to the furnace is equal to the return air supply under normal, indoor return air applications.

Exposure to the following substances in the combustion air supply will result in safety and performance related problems. The list below contains examples of chemical contaminants found in a wide variety of common commercial household products:

- Permanent wave solutions
- Chlorinated waxes and cleaners
- Chlorine based swimming pool chemicals
- Water softening chemicals
- De-icing salts or chemicals
- Carbon Tetrachloride
- Halogen type refrigerants
- Cleaning solvents (perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- Hydrochloric Acid
- Cements and glues
- Antistatic fabric softeners
- Masonry acid washing materials

| INSTALLATION CLEARANCES  |        |        |
|--------------------------|--------|--------|
|                          | CLOSET | ALCOVE |
| Front *                  | 1"     | 1"     |
| Rear                     | 0"     | 0"     |
| Sides                    | 0"     | 0"     |
| Top                      | 6"     | 6"     |
| Duct w/in 3ft of furnace | 1/4"   | 1/4"   |
| Vent                     | 0"     | 0"     |
| Plenum Without Coil Box  | 1"     | 1"     |
| Plenum With Coil Box     | 0"     | 0"     |



#### NOTES:

**Alcove Installations** - Allow 18 in. minimum clearance from front of unit to nearest wall or partition for servicing.

**Closet installations** - Require a return air grill installed in the door or a partially louvered door across the opening for proper air circulation. For clearances 6" or greater, the closet must have an open free area of 235 in<sup>2</sup> minimum. For special clearances between 1" - 5", requirements are a louvered door with a minimum of 250 in<sup>2</sup> (1613 cm<sup>2</sup>) free area. A fully louvered closet door is strongly recommended for both installation types.

## Heating Load

This furnace should be sized to provide the design heating load requirement. Heating load estimates can be made using approved methods available from Air Conditioning Contractors of America (Manual J); American Society of Heating, Refrigerating, and Air Conditioning Engineers; or other approved engineering methods. **Excessive oversizing of the furnace could cause the furnace and/or vent to fail prematurely.**

## Condensate Disposal

The method for disposing of condensate varies according to local codes. Consult your local code or authority having jurisdiction. Neutralizer kit P/N 902377 is available for use with this furnace. **Please follow the instructions provided with the kit.**

**Table 1. Minimum Clearance Requirements**

## COMBUSTION AIR & VENTING REQUIREMENTS

### **WARNING:**

#### CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death. The following steps shall be followed with each individual appliance connected to the venting system being placed in operation, while all other appliances connected to the venting system are not in operation:

1. Seal any unused openings in the venting system.
2. Inspect the venting system for proper size and horizontal pitch, as required in the National Fuel Gas Code, ANSI Z223.1/NFPA 54 or the CSA B149.1, Natural Gas and Propane Installation Codes and these instructions. Determine that there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.
3. As far as practical, close all building doors and windows and all doors between the space in which the appliance(s) connected to the venting system are located and other spaces of the building.
4. Close fireplace dampers.
5. Turn on clothes dryers and any appliance not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they are operating at maximum speed. Do not operate a summer exhaust fan.
6. Follow the lighting instructions. Place the appliance being inspected into operation. Adjust the thermostat so appliance is operating continuously.
7. Test for spillage from draft hood equipped appliances at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.
8. If improper venting is observed during any of the above tests, the venting system must be corrected in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or CSA B149.1, Natural Gas and Propane Installation Codes.
9. After it has been determined that each appliance connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-fired burning appliance to their previous conditions of use.

### **AVERTISSEMENT:**

#### RISQUE D'EMPOISONNEMENT AU MONOXYDE DE CARBONE

Le non-respect des consignes suivantes portant sur chacun des appareils raccordés au système d'évacuation mis en service pourrait entraîner l'empoisonnement au monoxyde de carbone ou la mort. Les consignes suivantes doivent être observées pour chaque appareil raccordé au système d'évacuation mis en service si les autres appareils raccordés au système ne sont pas en service:

1. Sceller toute ouverture non utilisée de la système d'évacuation;
2. S'assurer que la système d'évacuation présente des dimensions et une pente horizontale conformes à la norme ANSI Z223.1/NFPA 54, intitulée National Fuel Gas Code ou aux codes d'installation CSA-B149.1, ainsi qu'aux présentes instructions. S'assurer que la système d'évacuation n'est pas bloquée, restreinte, corrodée, qu'elle ne fuit pas et qu'elle ne présente aucun autre défaut potentiellement dangereux;
3. Dans la mesure du possible, fermer toutes les portes et fenêtres du bâtiment, et toutes les portes entre la pièce où se trouve l'appareil raccordé à la système d'évacuation et les autres pièces du bâtiment.
4. Fermer les registres des foyers;
5. Mettre en service les sècheuses et tout autre appareil qui n'est pas raccordé à la système d'évacuation. Faire fonctionner à régime maximal tout ventilateur d'évacuation, tel que les hottes de cuisinière et les ventilateurs de salles de bains. Ne pas mettre en service les ventilateurs d'été.
6. Respecter les instructions d'allumage. Mettre en service l'appareil à l'essai. Régler le thermostat de manière à ce que l'appareil fonctionne sans interruption;
7. Vérifier s'il y a débordement à l'orifice d'évacuation du coupe tirage des appareils dotés d'un coupe tirage 5 minutes après l'allumage du brûleur principal. Utiliser la flamme d'une allumette ou d'une chandelle.
8. Si l'on constate, au cours de l'un des essais qui précèdent, que l'évacuation est déficiente, corriger le système d'évacuation conformément à la norm ANSI Z223.1/NFPA 54, National Fuel Gas Code, et (ou) aux codes d'installation CSA B149.1.
9. Après avoir déterminé que tous les appareils raccordés à la système d'évacuation évacuent correctement tel que prescrit ci-dessus, rouvrir les portes et les fenêtres et remettre les ventilateurs d'évacuation, les registres de foyers et tout autre appareil fonctionnant au gaz à leur état de fonctionnement initial.

## Important Information

---

### **WARNING:**

**Furnace installation using methods other than those described in the following sections must comply with the National Fuel Gas Code (NFGC) and all applicable local codes.**

---

### **WARNING:**

**Upon completion of the furnace installation, carefully inspect the entire flue system both inside and outside the furnace to assure it is properly sealed. Leaks in the flue system can result in serious personal injury or death due to exposure of flue products, including carbon monoxide.**

---

### **WARNING:**

**This furnace must not be vented with other appliances, even if that appliance is of the condensing type. This includes water heaters of any efficiency. Common venting can result in severe corrosion of other appliances or their venting and can allow combustion gases to escape through such appliances or vents. Do not vent the furnace to a fireplace chimney or building chase.**

---

- This furnace must be vented in compliance with the current revision of the National Fuel Gas Code (ANSI-Z223.1/NFPA54). Instructions for determining the adequacy of combustion air for an installation can be found in the current revision of the NFGC (ANSI Z223.1 / NFPA54). Consult local codes for special requirements. These requirements are for US installations as found in the NFGC.
- The requirements in Canada (B149.1) are structured differently. In Canada, venting shall conform to the requirements of the current (CAN/CGA B149.1 or .2) installation codes. Consult local codes for special requirements.

### **Category IV Appliances**

This furnace is classified as a “Category IV” appliance, which requires special venting materials and installation procedures. Category IV appliances operate with positive vent pressure and requires thoroughly sealed vent systems. They also produce liquid condensate, which is slightly acidic and can cause severe corrosion of ordinary venting materials. Furnace operation can be adversely affected by restrictive vent and combustion air piping.

### **Direct Vent Installation**

This condensing furnace is certified for installation as a Direct Vent (2-pipe) appliance. Direct Vent (2-pipe) furnaces draw combustion air directly from the outdoors and then vent the combustion products back outside, isolating the entire system from the indoor space. It is important to make sure that the whole system is sealed and clearances to combustibles are maintained regardless of the installation being in a confined or unconfined space. This section specifies installation requirements for Direct Vent (2-pipe) piping. Table 2 (page 8) contains the length of vent and combustion air piping for this type of installation.

Provisions must be made during the installation of this furnace that provide an adequate supply of fresh air for combustion and ventilation. The combustion air from the outside needs to be clear of chemicals that can cause corrosion. The inlet pipe should not be placed near corrosive chemicals such as those listed on page 5.

Air openings on top of the furnace and openings in closet doors or walls must never be restricted. If the furnace is operated without adequate air for combustion, the flame roll-out switch will open, turning off the gas supply to the burners. **NOTE: This safety device is a manually reset switch. DO NOT install jumper wires across these switches to defeat their function or reset a switch without identifying and correcting the fault condition.** If a switch must be replaced, use only the correct sized part specified in the Replacement Parts List provided online.

### Vent Pipe Length & Diameter

For proper furnace operation, the combustion air and vent piping must not be excessively restrictive.

- The venting system should be designed to have the minimum number of elbows or turns.
- All horizontal runs must slope upwards from the furnace at 1/4 inch minimum per running foot of vent.
- Transition to the final vent diameter should be done as close to the furnace outlet as practical.
- Always use the same size or a larger pipe for combustion air that is used for the exhaust vent.

Table 2 (page 8) indicates the maximum allowable pipe length for a furnace of known input rate, when installed with piping of selected diameter and number of elbows. To use the table, the furnace input rate, the centerline length and the number of elbows on each pipe must be known.

When estimating the length of vent runs, consideration must be made to the effect of elbows and other fittings. This is conveniently handled using the idea of “equivalent length”. This means the fittings are assigned a linear length that accounts for the pressure drop they will cause. For example: a 3” diameter, long radius elbow is worth the equivalent of 3.5 feet of linear run.

The equivalent lengths of tees and various elbows are listed in Table 2. Measure the linear length of your vent run and then add in the equivalent length of each fitting. The total length, including the equivalent fitting lengths, must be less than the maximum length specified in the table.

Condensing furnace combustion products have very little buoyancy, so Table 2 is to be used without consideration of any vertical rise in the piping.

| MAXIMUM DIRECT VENT, DUAL PIPE LENGTH (FT.) |                            |                            |
|---|----------------------------|----------------------------|
| CMF95 INPUTS (BTU)                          | INLET / OUTLET 2" Diameter | INLET / OUTLET 3" Diameter |
| 45,000                                      | 30                         | 60                         |
| 72,000                                      | 30                         | 60                         |

†NOTES:

1. Subtract 2.5 ft. for each additional 2 inch long radius elbow, subtract 5ft for each additional 2" short radius elbow, subtract 3.5 ft. for each additional 3 inch long radius elbow, and 7 ft. for each additional 3 inch short radius elbow.
2. Two 45 degree elbows are equivalent to one 90 degree elbow.
3. This table applies for elevations from sea level to 2,000 ft. For higher elevations, decrease pipe lengths by 8% per 1,000 ft of altitude.

**Table 2. Vent Pipe Lengths**

**Vent Pipe Material**

Vent and combustion air pipe and fittings must be one of the following materials in the list and must conform to the indicated ANSI/ASTM standards.

| MATERIALS                     | STANDARDS |
|-------------------------------|-----------|
| Schedule 40PVC .....          | D1785     |
| PVC-DWV .....                 | D2665     |
| SDR-21 & SDR-26.....          | D2241     |
| ABS-DWV.....                  | D2661     |
| Schedule 40 ABS .....         | F628      |
| Foam / Cellular Core PVC..... | F891      |

When joining PVC to PVC, use cement that conforms to ASTM standard D2564. PVC primer must meet standard ASTM F656. When joining ABS to ABS, use cement that conforms to ASTM standard D2235. When joining PVC to ABS, use cement as specified in procedure from ASTM standard D3138.

In Canada, all plastic vent pipes and fittings including any cement, cleaners, or primers must be certified as a system to ULC S636. However this requirement does not apply to piping internal to the furnace.

Vent Pipe Installation

**⚠ CAUTION:**

**Combustion air must not be drawn from a corrosive atmosphere.**


This furnace has been certified for installation with zero clearance between vent piping and combustible surfaces. However, it is good practice to allow space for convenience in installation and service.

- In the absence of local codes, the location of any combustion air inlet relative to any vent terminal must be at least 8 inches. This includes installations involving more than one furnace.
- The quality of outdoor air must also be considered. Be sure that the combustion air intake is not located near a source of solvent fumes or other chemicals which can cause corrosion of the furnace combustion system. (See page 5 for a sample list of substances).


- Route piping as direct as possible between the furnace and the outdoors. Longer vent runs require larger diameters. Vent piping must be sloped upwards 1/4" per foot in the direction from the furnace to the terminal. This ensures that any condensate flows back to the condensate disposal system.
- When a Direct Vent (2-pipe) system is used, the combustion air intake and the vent exhaust must be located in the same atmospheric pressure zone. This means both pipes must exit the building through the same portion of exterior wall or roof as shown in Figure 20, page 33.
- Piping must be mechanically supported so that its weight does not bear on the furnace. Pipe supports must be installed a minimum of every five feet along the vent run to ensure no displacement after installation. Supports may be at shorter intervals if necessary to ensure that there are no sagging sections that can trap condensate. It is recommended to install couplings (Figure 20) along the vent pipe, on either side of the exterior wall. Couplings may be required by local code.
- If breakable connections are required in the combustion air inlet pipe (if present) and exhaust vent piping, then straight neoprene couplings for 2" or 3" piping with hose clamps can be used. These couplings can be ordered through your local furnace distributor. To install a coupling:
  1. Slide the rubber coupling over the end of the pipe that is attached to the furnace and secure it with one of the hose clamps.
  2. Slide the other end of the rubber coupling onto the other pipe from the vent.
  3. Secure the coupling with the second hose clamp, ensuring that the connection is tight and leak free.

**Outdoor Terminations - Horizontal Venting**


- Vent and combustion air intake terminations shall be installed as shown in Figures 1 & 2 (page 9) and in accordance with these instructions:
- Vent termination clearances must be consistent with the NFGC, ANSI 2223.1/NFPA 54 and/or the CSA B149.1, Natural Gas and Propane Installation Code. Table 12 (page 32) lists the necessary distances from the vent termination to windows and building air intakes.
- Vent and combustion air intake terminations must be located to ensure proper furnace operation and conformance to applicable codes. A vent terminal must be located at least 3 feet above any forced air inlet located within 10 feet. This does not apply to the combustion air inlet of a direct vent (two pipe) appliance. In Canada, CSA B149.1 takes precedence over these instructions. See Table 12 (page 32).
- All minimum clearances (Figure 2) must be maintained to protect building materials from degradation by flue gases.
- For optimal performance, vent the furnace through a wall that experiences the least exposure to winter winds.
- The vent termination shall be located at least 3 ft. horizontally from any electric meter, gas meter, regulator and any relief equipment. These distances apply ONLY to U.S. installations. In Canada, CSA B149.1 takes precedence over these instructions.



**Figure 1. Inlet & Exhaust Pipe Clearances**



**Figure 2. Vent Locations**




**Figure 3. Alternate Horizontal Vent Installation**

- Do not install the vent terminal such that exhaust is directed into window wells, stairwells, under decks or into alcoves or similar recessed areas, and do not terminate above any public walkways.
- If venting horizontally, side wall vent kits are available according to the pipe diameter size of the installation. For 3 inch pipe use kit #904347. Faceplate kit #902375 is also available for 3 inch horizontal venting. **Please follow the instructions provided with the kits.**
- Concentric vent kits are available for both 2" and 3" applications. Each size has one that meets UL 1738 and one that meets ULC S636. Refer to the technical sales literature for kit numbers.
- When the vent pipe must exit an exterior wall close to the grade or expected snow level where it is not possible to obtain clearances shown in Figure 1, a riser may be provided as shown in Figure 3. Insulation is required to prevent freezing of this section of pipe. See Table 3 (page 10) for vent freezing protection.

**Outdoor Terminations - Vertical Venting**

Termination spacing requirements from the roof and from each other are shown in Figure 4. The roof penetration must be properly flashed and waterproofed with a plumbing roof boot or equivalent flashing. Vent and combustion air piping may be installed in an existing chimney which is not in use provided that:

- Both the exhaust vent and air intake run the length of the chimney.
- The top of the chimney is sealed and weatherproofed.
- The termination clearances shown in Figure 4 are maintained.
- No other gas fired or fuel-burning equipment is vented through the chimney.



**Figure 4. Vertical Vent Termination**

## Vent Freezing Protection

### ⚠ CAUTION:

When the vent pipe is exposed to temperatures below freezing (i.e., when it passes through unheated spaces, chimneys, etc.) the pipe must be insulated with 1/2 inch thick sponge rubber insulation, Armaflex-type insulation or equivalent. Insulating pipe is important to avoid condensate icing.

- Table 3 lists the maximum length of flue pipe that can travel through an unconditioned space or an exterior space. The total vent length must not exceed the lengths noted in the Table. For Canadian installations, please refer to the Canadian Installation Code (CAN/CGA-B149.1 or 2) and/or local codes.
- For extremely cold climates or for conditions of short furnace cycles (i.e. set back thermostat conditions) the last 18 inches of vent pipe can be reduced. It is acceptable to reduce from 3" to 2-1/2" or, 3" to 2" if the total vent length is at least 15 feet in length, and the vent length is within the parameters specified in Table 2 (page 8). The restriction should be counted as 3 equivalent feet. Smaller vent pipes are less susceptible to freezing, but must not be excessively restrictive. .
- To prevent debris or creatures from entering the combustion system, a protective screen may be installed over the combustion air intake opening. The screens hole size must be large enough to prevent air restriction.

| Winter Design Temperature | Maximum Flue Pipe Length (FEET) in Unconditioned & Exterior Spaces |                  |
|---------------------------|--|------------------|
|                           | Without Insulation   | With Insulation* |
| 20                        | 45   | 70               |
| 0                         | 20   | 70               |
| -20                       | 10   | 60               |

\*NOTE: Insulation thickness greater than 3/8 inch, based on an R value of 3.5 (ft x F x hr) / (BTU x in.)

**Table 3. Vent Protection**


## Existing Installations

When an existing furnace is removed from a vent system serving other appliances, the existing vent system may not be sized properly to vent the remaining appliances (For example: water heater). An improperly sized venting system can result in the formation of condensate, leakage, or spillage. The existing vent system should be checked to make sure it is in compliance with NFGC and must be brought into compliance before installing the furnace.

**NOTE:** If replacing an existing furnace, it is possible you will encounter an existing plastic venting system that is subject to a Consumer Product Safety Commission recall. The pipes involved in the recall are High Temperature Plastic Vent (HTPV). **If your venting system contains these pipes DO NOT reuse this venting system!** This recall does not apply to other plastic vent pipes, such as white PVC or CPVC. Check for details on the CPSC website or call their toll-free number (800) 758-3688.

## VentilAire III or IV Air Quality Package (Accessory Item)

The VentilAire air quality packages are available to meet the ventilation requirements as outlined in H.U.D. Standard Part 3280.103 (b) (2). These packages introduce outdoor air into the living space during furnace blower operation. The VentilAire IV also serves to exhaust moist and/or hot air from the attic space. See Figure 5 for typical installation. Complete installation instructions are supplied with each air quality package.



**Figure 5. VentilAire III & IV**

## CIRCULATING AIR REQUIREMENTS

### **⚠ WARNING:**

**Do not allow combustion products to enter the circulating air supply. Failure to prevent the circulation of combustion products into the living space can create potentially hazardous conditions including carbon monoxide poisoning that could result in personal injury or death.**

**All supply ducts must be secured to the furnace with sheet metal screws and adequately sealed. When supply air is provided through the bottom of the unit, the joint between the furnace and the plenum must be air tight.**

**The surface that the furnace is mounted on must provide sound physical support of the furnace with no gaps, cracks or sagging between the furnace and the floor or platform.**

**Supply air ducts must not be connected to any other heat producing device such as a fireplace insert, stove, etc. This may result in fire, explosion, carbon monoxide poisoning, personal injury, or property damage.**

### **Plenums & Air Ducts**

This unit is designed only for use with a bottom supply duct and must be installed in accordance with the standards of the National Fire Protection Association Standard for Installation of Air Conditioning Systems (NFPA 90A), Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems (NFPA 90B), and all applicable local codes. NFPA publications are available by writing to: National Fire Protection Association, Batterymarch Park, Quincy, ME 02269 or visit [www.NFPA.org](http://www.NFPA.org) on the web.

- Design the air ducts according to methods described by the Air Conditioning Contractors of America (ACCA).
- Air ducts must be aluminum, tin plate, galvanized sheet steel, or other approved materials for outlet or return air ducts. Snap-Lock or Pittsburgh-Lock seams are preferred. All other types of seams must be made tight to prevent leakage.
- It is good practice to seal all connections and joints with industrial grade sealing tape or liquid sealant. Requirements for sealing ducts vary from region to region. Consult with local codes for requirements specific to your area.
- Gas piping must not run in or through any of the air duct system.

### **Supply Air Connections**

- The supply duct system must be designed so that the static pressure measured external to the furnace does not exceed the listed static pressure shown on the furnace rating plate. The supply air must be delivered to the heated space by duct(s) secured to the furnace casing, running full length and without interruption.

- Duct system must be designed so that no supply registers are located in duct system directly below the furnace.

### **Dampers**

An automated shut off damper is required when the home is air conditioned by a self-contained unit. A damper is required to prevent chilled air from flowing over the furnace heat exchanger. This damper is designed to fit in the feeder duct cavity, directly under the furnace. For proper installation, refer to the instructions provided with the damper. See replacement parts list provided online.

### **Unconditioned Spaces**

All duct work passing through unconditioned space must be properly insulated to minimize duct losses and prevent condensation. Use insulation with an outer vapor barrier. Refer to local codes for insulation material requirements


### **Closet Installations**

### **⚠ WARNING:**

**Failure to comply with the the following instructions may result in fire, asphyxiation or carbon monoxide poisoning.**

For proper air circulation, closet installations require a return air grill installed in the door or side wall that exchanges with the living area of the home as shown in Figure 6. A partially louvered door may also be used across the opening. Return air openings should not be located to draw air directly from a bathroom. Grilles placed in a side wall require a 6" clearance from the wall to the furnace so that the air may enter the front grille of the furnace. In addition, all return air systems, including the floor and ceiling systems, must meet the following conditions:

- The return air opening, regardless of its location in the closet, must not be smaller than size specified on unit data label. If located in the floor, the opening must be provided with a means of preventing its inadvertent closure by flat object(s) placed over the opening.



**Figure 6. Closet Installation**

- The return-air opening into the closet, regardless of its location, must have an open free area of 200 in<sup>2</sup> (1290 cm<sup>2</sup>) minimum.
- The cross-sectional area of the return duct system (in floor or ceiling) leading into the closet must not be less than 200 in<sup>2</sup> (1290 cm<sup>2</sup>).
- The total free area of the openings in the floor or the ceiling registers serving the return air duct system must not be less than 300 in<sup>2</sup> (1935 cm<sup>2</sup>).
- Materials located in the return duct system shall have a flame spread classification of 200 or less.
- Noncombustible pans having one inch upturned flanges are located beneath openings in a floor return duct system.
- Hollow spaces used as ducts or plenums for environmental air may contain mineral-insulated metal sheathed cable, aluminum sheathed cable, electrical metallic tubing, rigid metal conduit, flexible metal conduit (not to exceed 4 ft), or metal-clad cables. Wiring materials, fixtures, are to be suitable for the expected ambient temperatures to which they will be subjected.
- The negative pressure in the closet must not be less than minus 0.05 inches water column with the closet door closed and the fan operating at high speed. A reading below minus 0.05" indicates a dirty filter or a restricted return air system.
- For floor return systems, the manufacturer or installer shall affix a prominent marking on or near the appliance where it is easily read when the closet door is open. The marking shall read: "CAUTION, HAZARD OF ASPHYXIATION. DO NOT COVER OR RESTRICT FLOOR RETURN AIR OPENING." or equivalent.
- For closet installation with less than 6" front clearance, but not less than 1", a louvered door must be used having a minimum 200 in<sup>2</sup> (1290 cm<sup>2</sup>) free area opening directly in line with openings in the furnace door. A fully louvered door having the minimum free area is also permitted if the front tolerance is not less than 4".

## Furnace Filter

---

### **WARNING:**

---

**Never operate the furnace without a filter in place. Accumulating dust in the return air can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.**

---

- CMF95 furnaces are supplied with a single air filter when shipped from the factory. Accessing the filter does not require tools and can be easily removed from the inside of the access door. The filter is secured to the door with a retaining bracket. It is recommended that the filter be cleaned or replaced monthly. Newly built or recently renovated homes may require more frequent changing until the construction dust has minimized.
- Replacement filters are available at most local retailers. Inspect filters frequently and replace when necessary with filter of same dimensional size. Filters designed to remove smaller particles such as pollen, may require additional maintenance.

### **Acoustical Treatments**

Damping ducts, flexible vibration isolators, or pleated media-style filters on the return air inlet of the furnace may be used to reduce the transmission of equipment noise emanating from the furnace. These treatments can produce a quieter installation, particularly in the heated space. However, they can increase the pressure drop in the duct system. Care must be taken to maintain the proper maximum pressure rise across the furnace, temperature rise and flow rate. This may mean increasing the duct size and/or reducing the blower speed. These treatments must be constructed and installed in accordance with NFPA and SMACNA construction standards. Consult with local codes for special requirements. For best sound performance, install all the needed gaskets and grommets around penetrations into the furnace, such as for electrical wiring.

## FURNACE INSTALLATION

**NOTE:** Since all installations are different, the sequence of these steps may differ from the actual installation. These installation procedures are suggested for typical furnace installations. **Only qualified HVAC technicians should install this furnace.**

### General Information

The CMF95 furnace is designed only for indoor installations and can be readily connected to the high static duct system of a home. Units are approved for single/multistory residential or mobile/modular/manufactured structures in freestanding/closet/alcove downflow only configurations.

This appliance will provide many years of safe and dependable comfort, providing it is properly installed and maintained. Abuse, improper use, and/or improper maintenance can shorten the life of the appliance and create unsafe hazards. Please read all instructions before installing the unit.

Approved installation, operation, and maintenance of this appliance must be in accordance with the listed specifications contained in these instructions and other documents supplied with the furnace and/or optional air conditioning equipment. Unless it is noted differently in this manual, only use factory authorized kits and accessories when modifying this appliance. Refer to local authorities having jurisdiction for further information.

### Before You Install this Furnace

- √ This equipment is securely packaged at the time of shipment and upon arrival should be carefully inspected for damage prior to installing the equipment at the job site. Claims for damage (apparent or concealed) should be filed immediately with the carrier.
- √ Check the electrical supply and verify the power supply is adequate for unit operation. The system must be wired and provided with circuit protection in accordance with local building codes. If there is any question concerning the power supply, contact the local power company.
- √ Verify the air delivery of the furnace is adequate to handle the static pressure drop of the coil, filter, and duct work.

### Locating the Unit

- Survey the job site to determine the best location for installing the unit. Consideration should be given to availability of electric power, service access, and noise.
- The dimensions of the room or alcove must be able to accommodate the overall size of the unit and the installation clearances in Table 1 (page 5). Physical dimensions for this furnace are shown in Figure 17 (page 28).
- The unit must be leveled at installation and attached to a properly installed duct system.
- The surface that the furnace is mounted on must provide sound physical support of the unit.

## MA-200 Base Installation

The MA-200 base is designed for O.E.M. and replacement installation of the CMF95 series furnace. The warm air duct system should be designed so the duct static pressure external to the furnace does not exceed the static pressure listed on the furnace data label. Floor cut-outs must be carefully located to avoid misalignment of the furnace and air duct.

1. Using the base pan (Figure 7) as a guide, locate and mark the 12 1/8" x 12 1/8" opening for the Feeder Duct.
2. Cut all 4 sides of the Feeder Duct opening 1" larger than the drawn cutout. **NOTE:** Cutting the opening to 14-1/8" x 14-1/8" will allow the flanges on the underside of the base pan to fit in the opening.
3. Drill a 1" diameter hole for the gas line through the floor and bottom board to the outside. **NOTE:** Fuel lines are not supplied with the furnace. They should be installed to comply with all applicable codes.
4. Drop transition duct (Figure 8) upside down through the floor opening and center the top of the feeder duct in 14-1/8" x 14-1/8" floor opening. Using the feeder duct as a guide, mark and cut a 12" x 12" opening in the supply duct.
5. Insert the feeder tabs into the main duct and bend them over tightly so that the main duct edges are trapped between flanges and tabs. **NOTE:** Metal tape may be used to ensure an air tight connection.
6. Install the base pan around the feeder duct. Secure with 2 screws in the holes near the rear of the base pan.
7. Slit the corners of the feeder duct down to the top of the base pan (Figure 9). While the top of the distribution duct is pulled up with one hand, bend down each side of the feeder duct tightly to the base with the other hand. Trim the metal to allow a one inch flange over the top of the base pan and seal that flange with metal tape. **NOTE:** If using a "V" or "U"-box crossover system, use manufacturers instructions for installation details.

### Installing the Furnace on an MA-200 Base

1. Carefully lift the furnace over the base pan and set into position. The flange on the back of the furnace should rest on the inside rails of the base. **NOTE:** Installation on a MA-200 base may require removal of the front portion of the rails.
2. Raise the front of the furnace to clear the gasket on the bottom of the furnace and slide the back until the rear flange drops into the channel at the rear of the base. Make sure the furnace engages the tabs on the rear flange of the base.
3. Open the access door and fasten the front of the furnace and the base to the floor with #8 x 1/2" sheet metal screws.




Figure 7. MA-200 Base Pan




Figure 8. Transition Duct




Figure 9. Feeder Duct Installation

## MA-100 Universal Base Installation

The MA-100 base is designed primarily for replacement installation of the CMF95 series furnace where the manufactured home duct system may be too small or restrictive for proper air flow. The MA-100 base provides approximately 4 inches of additional plenum space before the discharge air enters the duct system. See Figure 10.

1. Using the universal base as a guide, locate and mark the 12-1/8" x 12-1/8" opening for the Feeder Duct.
2. Cut all 4 sides of the Feeder Duct opening 1" larger than the drawn cutout. **NOTE:** Cutting the opening to 14-1/8" x 14-1/8" will allow the four flanges on the underside of the panel to fit into the opening.
3. Drill a 1" diameter hole for the gas line through the floor and bottom board to the outside. **NOTE:** Fuel lines are not supplied with the furnace. They should be installed to comply with all applicable codes.
4. Set the universal base in place. Drop transition or offset feeder duct (Figure 8) upside down through the floor opening and center the top of the feeder duct in 14-1/8" x 14-1/8" floor opening.
5. Using the feeder duct as a guide, mark and cut a 12" x 12" opening in the supply duct. Remove the base and transition feeder duct; then cut the opening into the distribution duct.
6. Insert the feeder tabs into the main duct and bend them over until the main duct edges are trapped tightly between flanges and tabs. **NOTE:** Metal tape may be used to ensure an air tight connection.
7. Set the bottom base panel over the feeder duct. Slit the corners of the feeder duct down to the top of the base. While the top of the distribution duct is pulled up with one hand, bend down each side of the feeder duct tightly to the base with the other hand. Trim the metal to allow one inch flange over the top of the base and seal that flange with metal tape.





Figure 10. MA-100 Universal Base, Bottom Panel

- Secure the top panel to the floor with 2 screws through the front flange. **NOTE:** If using a “V” or “U”-box crossover system, use manufacturers instructions for installation details.

### Installing the Furnace on an MA-100 Base

- Carefully lift the furnace over the universal base pan and set into position. Avoid damaging the feeder duct assembly. **NOTE:** Make sure the furnace is positioned against the back end of the base.
- Open the furnace door and fasten the furnace to the base using #8 x 1/2” sheet metal screws.



**Figure 11. Condensate Drainage**

## Condensate Drainage

### **⚠ WARNING:**

**The condensate produced by the furnace must be drained. Do not connect a water supply to the drainage hose of the furnace.**

### **⚠ CAUTION:**

**Do not install additional traps in the condensate drain.**

- If the furnace is installed in an area where temperatures fall below freezing, special precautions must be made for insulating condensate drain lines that drain to the outdoors. If condensate freezes in the lines, this will cause improper operation or damage to the furnace. It is recommended that all drain lines on the outside of the residence be wrapped with an industry approved insulation or material allowed by local code.
  - Before routing the drain tube out of the furnace, loosen the tube clamp and turn the tube so the preset 90° turn faces the intended direction of exit from the cabinet. Do not route the drain tube without rotating the tube first. This will kink the tube and prevent condensate from draining.
  - Care should be taken to route the drain line away from the burner box. Drain lines resting on the burner box can become kinked or collapsed due to the heat from the burner box.
  - The condensate drain may exit through the left or right slots in the bottom of the furnace (Figure 11). Make sure the flexible drain hose is not kinked.
  - The condensate should drain from the plastic collector box as droplets or a small stream. If you notice the furnace has operated for more than 5 minutes without draining or the status lights on the control board indicates an open pressure switch (Table 6, page 27) follow the steps below.
- Remove the collector box soft tube (Figure 11) and verify the exit from the collector box is clear of any debris or obstructions.
  - Replace this tube and verify the fit to the header spout is air tight. Air will be drawn into the header if this connection is not tight.
  - Check other tube connections along the drain system. Verify that all are air tight.

## GAS SUPPLY & PIPING

### **WARNING:**

#### **FIRE OR EXPLOSION HAZARD**

- Failure to follow safety warnings exactly could result in serious injury or property damage.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

#### **WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

### **AVERTISSEMENT :**

#### **RISQUE D'INCENDIE OU D'EXPLOSION**

- Le non-respect des avertissements de sécurité pourrait entraîner des blessures graves ou des dommages matériels.
- L'installation et l'entretien doivent être effectués par un installateur qualifié, un organisme de service ou le fournisseur de gaz.
- Ne pas entreposer ni utiliser de l'essence ni d'autres vapeurs ou liquides inflammables dans le voisinage de cet appareil, ni de tout autre appareil.

#### **QUE FAIRE S'IL Y A UNE ODEUR DE GAZ**

- Ne tentez pas d'allumer quelque appareil que ce soit.
- Ne touchez à aucun interrupteur électrique; n'utilisez pas de téléphone dans votre immeuble.
- Évacuer l'immeuble immédiatement.
- Appelez immédiatement votre fournisseur de gaz à l'aide du téléphone d'un voisin. Suivez les directives données par le fournisseur de gaz.
- Si vous ne pouvez pas joindre le fournisseur de gaz, appelez les pompiers.

- All gas piping must be installed in compliance with local codes and utility regulations. In the absence of local codes the gas line installation must comply with the latest edition of the Federal Manufactured Home Construction & Safety Standard (H.U.D. Title 24, Part 3280.707[a][2]), National Fuel Gas Code (ANSI Z223.1 /NFPA 54) or (CAN/CGA B149.1 or .2) Installation Codes.

- Some local regulations require the installation of a manual main shut-off valve and ground joint union external to the furnace as shown in Figure 12 (page 17). The shut-off valve should be readily accessible for service and/or emergency use. Consult the local utility or gas supplier for additional requirements regarding placement of the manual main gas shut-off.
- Per ANSI 21.47, A 1/8-inch NPT plugged tapping, accessible for test gauge connection, must be installed immediately upstream of the gas supply connection to the furnace external to the cabinet. If local codes allow the use of a flexible gas appliance connector, always use a new listed connector. Do not use a connector that has previously serviced another gas appliance.
- Gas piping must never run in or through air ducts, chimneys, gas vents, or elevator shafts.
- Compounds used on threaded joints of gas piping must be resistant to the actions of LP propane gas.
- The main gas valve and main power disconnect to the furnace must be properly labeled by the installer in case emergency shutdown is required.
- Flexible gas connectors are not recommended for this type of furnace but may be used if allowed by local jurisdiction. Only new flexible connectors may be used. Do not use a connector which has previously serviced another gas appliance.
- A drip leg should be installed in the vertical pipe run to the unit if not entering the furnace through the floor.

Table 8 (page 30) lists gas flow capacities for standard pipe sizes as a function of length in typical applications based on nominal pressure drop in the line.

The furnace is installed with a bottom gas entry. When connecting the gas supply, provide clearance between the gas supply line and the entry hole in the furnace casing to avoid unwanted noise and/or damage to the furnace. Typical gas hookups are shown in Figure 12.

### Leak Check

### **WARNING:**

#### **FIRE OR EXPLOSION HAZARD**

Failure to follow safety warnings exactly could result in serious injury or property damage.

Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.

## **⚠ AVERTISSEMENT :**

### **RISQUE D'INDENDIE OU D'EXPLOSION**

Le non-respect des avertissements de sécurité pourrait entraîner des blessures graves, la mort ou des dommages matériels.

Ne jamais utiliser une flamme nue pour vérifier la présence de fuites de gaz. Pour la vérification de tous les joints, utiliser plutôt une solution savonneuse commerciale fabriquée spécifiquement pour la détection des fuites de gaz. Un incendie ou une explosion peut entraîner des dommages matériels, des blessures ou la mort.




Figure 12. Typical Gas Connections

After the gas piping to the furnace is complete, all connections must be tested for gas leaks. This includes pipe connections at the main gas valve, emergency shutoff valve and flexible gas connectors (if applicable). The soap and water solution can be applied on each joint or union using a small paintbrush. If any bubbling is observed, the connection is not sealed adequately and must be retightened. Repeat the tightening and soap check process until bubbling ceases.

### **IMPORTANT NOTE**

**When pressure testing gas supply lines at pressures greater than 1/2 psig (14 inch W.C.), the gas supply piping system must be disconnected from the furnace to prevent damage to the gas control valve. If the test pressure is less than or equal to 1/2 psig (14 inch W.C.), close the manual shut-off valve.**

### **High Altitude Application**

High altitude conversion with this furnace depends on the installation altitude and the heating value of the gas. Installation of this furnace at altitudes above 2,000 feet shall be in accordance with local codes, or in the absence of local codes, the National Fuel Gas Code, ANSI Z223/NFPA 54 or National Standard of Canada, Natural Gas & Propane Installation Code CGA B149.1. Please consult your local code authority.

**The installer must indicate the furnace has been converted to high altitude. This may be accomplished by marking the rating plate with a permanent marker.**

## **⚠ WARNING:**

**The reduction of input rating necessary for high altitude installation may only be accomplished with factory supplied orifices. Do not attempt to drill out orifices in the field. Improperly drilled orifices may cause fire, explosion, carbon monoxide poisoning, personal injury or death.**

The furnaces are shipped from the factory with orifices and gas regulator settings for natural gas operation at sea level altitudes. At 2000 feet, the NFGC requires that this appliance be derated 4% for each 1000 feet of altitude. For example, the input needs to be reduced 8% at 2,000 feet, 12% at 3,000 feet, etc. This deration is in reference to the input rate and gas heating value at sea level.

To derate the furnace requires knowing the heating value of the gas at the installation site. Heating values at particular job sites vary for two reasons:

1. The chemical mixture of the gas varies across regions and is expressed as the "sea level heating value".
2. The heating value varies by altitude. For this reason, especially in high altitude areas, the local gas utility specifies the heating value at the residence's gas meter as the "local value".

For added flexibility, two tables have been provided for natural gas installations with high or low heating values at sea level. Tables 11 and 12 (page 31) contain the manifold pressure and orifice sizes to use at various altitudes. Table 11 (HIGH) is for natural gas installations with a heating value of more than 1,000 Btu per cubic foot and Table 12 (LOW) is for less than 1,000 Btu per cubic foot. To determine which table to use:

1. Consult the local utility for the local heating value at your installation site.
2. From Table 10 (page 31), find your local heating value as supplied by the utility company. Follow down the column and stop at your altitude level.
3. If your sea level heating value is HIGH, use Table 11 or if it's LOW, use Table 12. See example below.

After changing the orifices, it is required that you measure the gas input rate. This may be accomplished in the usual way, by clocking the gas meter and using the local gas heating value. See Verifying and Adjusting the Input Rate section (page 23).

**IMPORTANT NOTE:**

Observe the action of the burners to make sure there is no yellowing, lifting or flashback of the flame.

| <b>Installation Example</b>  |             |
|--|-------------|
| Elevation: .....   | 5,000 feet  |
| Type of Gas: .....   | Natural Gas |
| Local Heating Value of Gas: .....  | 750         |
| <p>From Table 10, find 750 and follow down the column, stop at the 5,000 feet row. The heating value listed is LOW. Table 12 will be used to determine orifice size and manifold pressure.</p> |             |

**Converting to LP/Propane Gas at Altitudes between 0 & 10,000 FT.**

**⚠ WARNING:**

The furnace was shipped from the factory equipped to operate on natural gas. Conversion to LP / Propane gas must be performed by qualified service personnel using a factory supplied conversion kit. Failure to use the proper conversion kit can cause fire, explosion, property damage, carbon monoxide poisoning, personal injury, or death.

Converting single stage valves to LP/Propane requires the replacement of the burner orifices and flipping the regulator cap to the side marked LP. The end facing up should now read LP. See Figure 13.

**⚠ WARNING:**

Shut off the gas supply at the manual gas shutoff valve, before disconnecting the electrical power. A fire or explosion may result causing property damage, personal injury or loss of life. Failure to follow the safety warnings exactly could result in serious injury, death or property damage.

**⚠ WARNING:**

To avoid electric shock, personal injury, or death, turn off the electric power at the disconnect or the main service panel before making any electrical connections.

**⚠ WARNING:**

The reduction of input rating necessary for high altitude installation may only be accomplished with factory supplied orifices. Do not attempt to drill out orifices in the field. Improperly drilled orifices may cause fire, explosion, carbon monoxide poisoning, personal injury or death.




Figure 13. Gas Valve




Figure 14. Orifice Removal

### Removing The Burner Orifices

1. Set the thermostat to the OFF position, or its lowest temperature setting.
2. Shut OFF the gas supply at the manual shutoff valve located outside of the appliance.
3. Turn off all electrical power to the appliance.
4. Remove the door from the burner box by removing 6 screws.
5. Turn the gas valve ON/OFF knob to the OFF position. See Figure 14.
6. Remove the wires from the terminals of the gas valve.
7. Remove the supply gas piping from the gas valve inlet.
8. Carefully remove four screws securing the gas manifold assembly to the burner assembly.
9. Set the screws aside and remove the gas manifold assembly from the appliance.
10. Carefully remove the burner orifices from the gas manifold assembly.
11. Read the rating plate affixed to the appliance to determine its rated input (Btu/hr) and the size of the factory installed orifices.

#### IMPORTANT NOTE:

**Before installing an orifice, check the side or face of the orifice for the drill number to ensure that it is the appropriate size.**

12. Install the appropriate LP/Propane gas burner orifices into the gas manifold assembly. **NOTE:** The orifices are included with the furnace. To prevent cross threading, hand tighten the orifices into the gas manifold assembly until snug, then tighten with a wrench.
13. Unscrew the gas valve pressure regulator cap marked NAT. Invert the cap so LP faces up. Reinstall the cap and tighten until snug. Make sure LP is visible after conversion.

### WARNING:

**Do not use Teflon tape or pipe joint compound on the orifice threads. The hole in the orifice may become blocked and cause fire, explosion, property damage, carbon monoxide poisoning, personal injury, or death.**

14. Reinstall the gas manifold assembly to the burner assembly with the 4 screws, that were removed earlier. **NOTE:** It is important that the center of the orifices are aligned with the center of the burners.
15. Reinstall the burner box door with the 6 screws that were removed earlier in step 4.
16. Reconnect the gas piping to the gas valve inlet.
17. Reconnect the wires to the gas valve terminals.

### Gas Pressure Verification

#### Measuring the Supply Gas Pressure

1. Turn OFF the gas supply at the manual valve located on the outside of the unit.
2. Using a 3/16" Allen wrench, remove the plug from the inlet pressure tap (INLET side of gas valve). See Figure 13 (page 18).
3. Install an 1/8" NPT pipe thread fitting, that is compatible with a Manometer or similar pressure gauge.
4. Connect the Manometer or pressure gauge to the Inlet Pressure Tap.
5. Turn ON the main gas supply at the manual valve.
6. Check and adjust the incoming gas line pressure to 11.0-14.0 inches Water Column for LP/Propane gas.
7. Turn OFF the gas supply at the manual valve.
8. Disconnect the Manometer or pressure gauge.
9. Remove the NPT fitting and reinstall the INLET pressure tap plug. Hand tighten the plug first to prevent cross-threading. Tighten with 3/16 Allen wrench.

## Lighting & Adjustment of the Appliance

---

### **WARNING:**

---

#### **FIRE OR EXPLOSION HAZARD**

**Failure to follow safety warnings exactly could result in serious injury or property damage.**

**Never test for gas leaks with an open flame. Use a commercially available soap solution made specifically for the detection of leaks to check all connections. A fire or explosion may result causing property damage, personal injury or loss of life.**

---

1. Turn ON the manual gas valve, located on the outside of the unit to the ON position.
2. Check all gas connections for leaks with a soap and water solution. If the solution bubbles there is a gas leak which must be corrected.
3. Turn on the electrical power to the appliance.
4. Turn the gas valve ON/OFF knob to the ON position. See Figure 13 (page 18).
5. Set the thermostat to a point above room temperature to begin the heating cycle of the furnace.
6. Check that the furnace ignites and operates properly. Refer to the installation instructions provided with the unit for the normal operating sequence.
7. After ignition, visually inspect the burner assembly to ensure that the flame is drawn directly into the center of the heat exchanger tube. In a properly adjusted burner assembly, the flame color should be blue with some light yellow streaks near the outer portions of the flame.

**NOTE:** The igniter may not ignite the gas until all air is bled from the gas line. If the ignition control locks out, turn the thermostat to its lowest setting and wait one minute then turn the thermostat to a point above room temperature and the igniter will try again to ignite the main burners. This process may have to be repeated several times before the burners will ignite. After the burners are lit, check all gas connections for leaks again with the soap and water solution.

## Measuring the Manifold Pressure

The manifold pressure must be measured by installing a pressure gauge (Manometer, Magnehelic Meter, etc.) to the outlet end of the gas valve as follows:

1. Turn off all electrical power to the appliance.
2. Shut OFF the gas supply at the manual shutoff valve located outside of the appliance.
3. Using a 3/16" Allen wrench, remove the manifold pressure tap plug located on the outlet side of the gas valve. See Figure 13 (page 18).
4. Install an 1/8" NPT pipe thread fitting, that is compatible with a Manometer or similar pressure gauge.
5. Connect the Manometer or pressure gauge to the manifold pressure tap.
6. Set the room thermostat above room temperature to start the furnace.
7. Allow the furnace to operate for 3 minutes and then check the manifold pressure. Compare the measured value with the value shown in Table 11 (page 31).

## Removing the Manometer/Pressure Gauge

After the manifold pressure is verified, the Manometer or pressure gauge must be removed from the gas valve.

1. Turn the thermostat to its lowest setting.
2. Turn OFF the main gas supply to the unit at the manual shut-off valve, which is located outside of the unit.
3. Turn OFF all of the electrical power supplies to the unit.
4. Remove the pressure gauge adapter from the gas valve and replace it with the 1/8" NPT manifold pressure plug that had been removed earlier. **NOTE:** Make sure the plug is tight and not cross-threaded.
5. Turn ON the electrical power to the unit.
6. Turn ON the main gas supply to the unit at the manual shut-off valve.

## Completing the Conversion

---

### **WARNING:**

---

**Do not alter or remove the original rating plate from the furnace.**

---

1. Affix the LP label from the orifice package to the rating plate.
2. Reinstall the appliance door.
3. Run the appliance through 3 complete cycles to assure proper operation.

## ELECTRICAL WIRING

### **WARNING:**

#### **ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD**

Failure to follow safety warnings exactly could result in serious injury or property damage.

Improper servicing could result in dangerous operation, serious injury, death or property damage.

- Before servicing, disconnect all electrical power to furnace.
- When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.
- Verify proper operation after servicing.

### **AVERTISSEMENT :**

#### **RISQUE DE DÉCHARGE ÉLECTRIQUE, D'INCENDIE OU D'EXPLOSION**

Le non-respect des avertissements de sécurité pourrait entraîner des blessures graves ou des dommages matériels.

Un entretien inapproprié peut provoquer un fonctionnement dangereux, des blessures graves, la mort ou des dommages matériels.

- Avant toute intervention, couper l'alimentation électrique du générateur d'air chaud.
- Pour l'entretien des commandes, étiqueter tous les fils avant de les débrancher. Rebrancher les fils correctement.
- Vérifier le bon fonctionnement après l'intervention.

### **Line Voltage Wiring**

- Electrical connections must be in compliance with all applicable local codes with the current revision of the National Electric Code (ANSI/NFPA 70).
- For Canadian installations the electrical connections and grounding shall comply with the current Canadian Electrical Code (CSA C22.1 and/or local codes).
- It is recommended that the line voltage (115 VAC) to the furnace be supplied from a dedicated branch circuit containing the correct fuse or circuit breaker for the furnace as listed in Table 4 (page 22).

## IMPORTANT NOTES

If replacing any of the original wires supplied with the furnace, the replacement wire must be copper wiring and have a temperature rating of at least 105°F (40°C). For electrical specifications, refer to the furnace nameplate or Table 4.

An electrical disconnect must be installed readily accessible from and located within sight of the furnace. See Figure 18 (page 29) or the wiring diagram label inside of the control door. Any other wiring methods must be acceptable to authority having jurisdiction.

Proper line voltage polarity must be maintained in order for the control system to operate correctly. Verify the incoming neutral line is connected to the white wire and the incoming HOT line is connected to the black wire. The furnace will not operate unless the polarity and ground are properly connected as shown in Figure 18.

### **Grounding**

### **WARNING:**

To minimize personal injury, the furnace cabinet must have an uninterrupted or unbroken electrical ground. The controls used in this furnace require an earth ground to operate properly. Acceptable methods include electrical wire or conduit approved for ground service. Do not use gas piping as an electrical ground!

### **Thermostat / Low Voltage Connections**

- The furnace is designed to be controlled by a 24 VAC thermostat. The thermostat's wiring must comply with the current provisions of the NEC (ANSI/NFPA 70) and with applicable local codes having jurisdiction.
- The thermostat must be installed according to the instructions supplied by the thermostat manufacturer. Low voltage connections (24 VAC) from the thermostat are wired to the terminal strip on the integrated control in the furnace. Figure 15 (page 22) contains the proper connections for heating only (two-wire) and heating/cooling (four-wire) applications. Recommended minimum wire gauge for thermostat wiring is shown in Table 4 (page 22).
- The thermostat should be mounted about 5 feet above the floor on an inside wall. DO NOT install the thermostat on an outside wall or any other location where its operation may be adversely affected by radiant heat from fireplaces, sunlight, or lighting fixtures, and convective heat from warm air registers or electrical appliances. Refer to the thermostat manufacturer's instruction sheet for detailed mounting information.

## Heat Anticipator

Set the heat anticipator according to the instructions supplied by the thermostat manufacturer. To determine the heat anticipator setting:

1. Add the current draw of the system components; or
2. Measure the current flow on the thermostat **R-W** circuit after the circulating blower motor has started.




Figure 15. Low Voltage Field, Four-wire Heating/Cooling Applications

| Furnace Model Number CMF95- | Furnace Input (Btuh) | Cabinet Width (in.) | Nominal Electrical Supply | Maximum Operating Voltage | Minimum Operating Voltage | Maximum Furnace Amperes | Maximum Fuse or Circuit Breaker Amps* | Minimum Circuit Ampacity <sup>1</sup> |
|-----------------------------|----------------------|---------------------|---------------------------|---------------------------|---------------------------|-------------------------|---------------------------------------|---------------------------------------|
| 045                         | 45,000               | 18                  | 115-60-1                  | 127                       | 103                       | 8.5                     | 15                                    | 10.56                                 |
| 072                         | 72,000               | 18                  | 115-60-1                  | 127                       | 103                       | 10.8                    | 20                                    | 13.44                                 |

**NOTE:** Minimum wire gauge and maximum fuse/circuit breaker amperage are based on MCA<sup>1</sup> and MOP<sup>2</sup> calculations. This furnace is approved for installation with a 15 or 20 amp fuse/circuit breaker however wiring sizing must adhere to current version of the NEC and/or applicable local codes depending upon the overcurrent protection.

| Thermostat Wire Gauge | Recommended Thermostat Wire Length |                       |
|-----------------------|------------------------------------|-----------------------|
|                       | 2 - wire - Heating                 | 4 or 5 wire - Cooling |
| 24                    | 55 ft.                             | 25 ft.                |
| 22                    | 90 ft.                             | 45 ft.                |
| 20                    | 140 ft.                            | 70 ft.                |
| 18                    | 225 ft.                            | 110 ft.               |

\* Time-delay fuses or circuit breakers are required.

Table 4. Wire Length & Voltage Specifications




Figure 16. Line Voltage Field Wiring

## START-UP & ADJUSTMENTS

### Pre-Start Check List

- √ Verify the polarity of the connections are correct, the line voltage power leads are securely connected and the furnace is properly grounded.
- √ Verify the thermostat wires (**R, W, Y, & G**) are securely connected to the correct leads on the terminal strip of the circuit board.
- √ Verify the gas line service pressure does not exceed 10.0 inches of W.C., and is not less than 4.5 inches W.C. for natural gas. For LP gas the line service pressure must not exceed 14 in. W.C., and must not be less than 11.0 in. W.C.
- √ Verify the roll-out and vent switches are closed. If necessary, press the red button to reset a switch. **DO NOT install a jumper wire across a switch to defeat its function. If a switch reopens on startup, DO NOT reset the switch without identifying and correcting the fault condition.**
- √ Verify the blower door is in place, closing the door switch in the line voltage circuit.
- √ Verify the gas line has been purged and all connections are leak free.

### Start-up Procedures

Do not perform these steps until all of the checks in the previous steps have been completed:

1. Set the thermostat to the lowest setting.
2. Turn off all electrical power to the furnace.
3. Follow the Operating Instructions on the label attached to the furnace.
4. Set the thermostat above room temperature and verify the Operating Sequence (page 25).
5. After 5 minutes of operation, set the thermostat below room temperature and verify steps 9 - 10 of the Operating Sequence.

### Verifying & Adjusting Input Rate

The input rate must be verified for each installation to prevent over-firing of the furnace. **NOTE:** The input rate must not exceed the rate shown on the furnace rating plate. At altitudes above 2,000 feet, it must not exceed that on the rating plate less 4% for each 1,000 feet. To determine the exact input rate, perform the following procedures:

1. Shut off all other gas fired appliances.
2. Start the furnace and run it for at least 3 minutes.
3. Measure the time (in seconds) required for the gas meter to complete one revolution.
4. Convert the time per revolution to cubic feet of gas per hour using Table 7 (page 30).
5. Multiply the gas flow rate in cubic ft per hr by the heating value of the gas in Btu per cubic ft to obtain the input rate in Btuh. See example.
6. The manifold pressure must be set to the appropriate value for each installation by a qualified installer, service agency or the gas supplier.

#### Example:

- Time for 1 revolution of a gas meter with a 1 cubic ft dial = 40 seconds.
- From Table 7 read 90 cubic ft gas per hr.
- Local heating value of the gas (obtained from gas supplier) = 1,040 Btu per cubic ft.
- Input rate = 1,040 x 90 = 93,600 Btuh.

## WARNING:

**Do not attempt to drill the gas orifices. Use only factory supplied orifices. Improperly drilled orifices may cause fire, explosion, carbon monoxide poisoning, personal injury or death.**

- a.) Obtain the manifold pressure setting required for this installation by referring to Table 11 for Propane or Table 12 (page 31) for Natural Gas.
- b.) Remove the regulator capscrew from the INLET side of the regulator. See Figure 30, page 30 - gas valve picture in LP section.
- c.) Slowly turn the adjustment screw inside the regulator to obtain the appropriate manifold pressure. **NOTE:** Turning the screw clockwise increases the pressure and turning the screw counter-clockwise decreases the pressure. To prevent backing the screw all the way out from the valve, turn the screw slowly.
- d.) Replace and tighten the regulator capscrew over the adjustment screw.

### Verifying & Adjusting Temperature Rise

After installation of the furnace, confirm the temperature rise of the furnace is within the limits specified on the rating plate. Any temperature rise outside the specified limits could result in premature failure of the heat exchanger.

For typical duct systems, the temperature rise will fall within the limits specified on the rating plate with the blower speed at the factory recommended setting. If the measured temperature rise is outside the specified limits, it may be necessary to change the speed of the blower.

**NOTE:** Lowering the blower speed will increase the temperature rise and a higher blower speed will decrease the temperature rise.

The furnace is equipped with a multi-speed motor. Heating and cooling speed selection is made by moving the switch on the integrated control located in the furnace.

1. Place thermometers in the return and supply air stream as close to the furnace as possible.

#### IMPORTANT NOTE

**The thermometer on the supply air side must be shielded from direct radiation from the heat exchanger to avoid false readings.**

2. Consult Table 5 (page 24) and the rating plate for the proper circulating air flow and temperature rise.

**NOTE:** This furnace is designed to operate with a maximum external pressure rise of 0.3 inches of water column. It is important that the duct system be designed to provide the correct flow rates and external pressure rise. An improperly designed duct system can result in nuisance shutdowns, and comfort or noise issues.

- Adjust all registers and duct dampers to the desired position and run the furnace for 10 to 15 minutes before taking any temperature readings. The temperature rise is the difference between the supply and return air temperatures.

### Verifying Burner Operation

#### **CAUTION:**

**The door over the burners may only be open for inspection purposes only. The door must be installed during unattended operation.**

- Set the thermostat above room temperature and observe the ignition sequence. **NOTE:** The burner flame should carry over immediately between all burners without lifting off, curling, or floating. The flames should be blue, without yellow tips.
- After validating the flame, change thermostat setting to below room temperature.
- Verify the burner flame is completely extinguished.
- Replace the burner compartment door.

### Verifying Operation of the Supply Air Limit Switch

**Note:** A properly functioning limit switch should turn off the gas valve when the return is blocked (time depends on how well the return air is blocked). The circulating air and combustion blowers should continue to run when the limit switch opens.

- Verify the blower door is securely mounted in place and that there is power to the furnace.
- Block the return airflow to the furnace by installing a close-off plate in place of or upstream of the filter(s).
- Set the thermostat above room temperature and observe the Operating Sequence.
- Remove the close-off immediately after the limit switch opens. If the furnace continues to operate with no return air, set the thermostat below room temperature, shut off power to the furnace, and replace the limit switch.

| MODEL NUMBER & HEATING INPUT (BTUH) | MOTOR SPEED   | EXTERNAL STATIC PRESSURE (INCHES WATER COLUMN) |      |       |      |       |      |       |      |       |      |
|-------------------------------------|---------------|--|------|-------|------|-------|------|-------|------|-------|------|
|                                     |               | 0.1  |      | 0.2   |      | 0.3   |      | 0.4   |      | 0.5   |      |
|                                     |               | CFM  | RISE | CFM   | RISE | CFM   | RISE | CFM   | RISE | CFM   | RISE |
| CMF95 045<br>45,000                 | 5 - High**    | 1,280  | 31   | 1,240 | 32   | 1,200 | 33   | 1,165 | 34   | 1,130 | 35   |
|                                     | 4 - Med-High  | 1,235  | 32   | 1,195 | 33   | 1,150 | 34   | 1,110 | 36   | 1,075 | 37   |
|                                     | 3 - Med-Low   | 1,110  | 36   | 1,060 | 37   | 1,015 | 39   | 980   | 40   | 930   | 43   |
|                                     | 2 - Alternate | 1,025  | 39   | 975   | 41   | 930   | 43   | 885   | 45   | 830   | 48   |
|                                     | 1 - Low***    | 870  | 45   | 815   | 49   | 765   | 52   | 710   | 56   | 665   | 60   |
| CMF95 072<br>72,000                 | 5 - High**    | 1,455  | 44   | 1,425 | 44   | 1,390 | 46   | 1,360 | 47   | 1,330 | 48   |
|                                     | 4 - Med-High  | 1,455  | 44   | 1,425 | 44   | 1,390 | 46   | 1,360 | 47   | 1,330 | 48   |
|                                     | 3 - Med-Low   | 1,275  | 50   | 1,245 | 51   | 1,205 | 53   | 1,170 | 54   | 1,135 | 56   |
|                                     | 2 - Alternate | 1,245  | 51   | 1,210 | 52   | 1,175 | 54   | 1,140 | 56   | 1,100 | 58   |
|                                     | 1 - Low***    |  |      |       |      |       |      |       |      |       |      |

**NOTES:**

- Data is shown without filter.
  - Temperature rises (° F) in the table are approximate. Actual temperature rises may vary.
  - Individual cells shaded in gray indicate a temperature rise outside of the recommended range.
  - To comply with government mandated efficiency standards, speed settings shaded in gray are not allowed in HEAT mode.
  - Unit ships with (4) speeds pre-wired. Use of the fifth speed will require changing the appropriate wires at the motor connection. Consult the wiring diagram for more information.
- \*\* Factory Set Heat.  
\*\*\* Factory Set Circulation.

**Table 5. Maximum Airflow & Temperature Rises (° F)**

## OPERATING SEQUENCE

The operating sequences for the heating, cooling, and fan modes are described below. Refer to the field and furnace wiring diagrams: (Figures 15 & 16, page 31) and (Figure 18 page 28).

### Heating Cycle

1. The thermostat calls for heat by energizing the **W** terminal with 24VAC.
2. The control verifies the pressure switch is open.
3. If the pressure switch is open, the control energizes the inducer and waits for the pressure switch to close. The pressure switch must close within 10 seconds.
4. The control runs the inducer for a 30 second pre-purge.
5. The control energizes the Hot Surface Igniter (HSI) output for the appropriate warm-up time limit.
6. The control energizes the main gas valve for 3 seconds.
7. If the flame proved and ignites the gas, the control de-energizes the HSI. The gas valve and inducer remains energized. The control goes to blower on delay.
8. If flame is present, the control energizes the blower on the selected HEAT speed 30 seconds after the gas valve opened. The gas valve and inducer remain energized.
9. When the thermostat demand for heat is satisfied, the control de-energizes the gas valve. The Inducer output remains on for a 30 second post-purge period.
10. Blower off timing begins when the thermostat is satisfied. The control will operate at the selected HEAT speed of 60, 90, 120, or 180 seconds. If the blower off delay jumper is not present, the fan should still operate for 120 seconds at the selected HEAT speed. The Indoor blower motor is de-energized after a blower off delay as selected by the movable jumper.

### Cooling Cycle

1. The thermostat calls for cooling by energizing the **Y** terminal with 24VAC.
2. The control energizes the blower in cooling speed and sends 24VAC to the contactor in the condensing unit
3. When the thermostat removes the call for cooling, the contactor in the outdoor condensing unit is de-energized and the control continues to run the fan for a period of 60 seconds.

### Fan Mode

- When the thermostat energizes the **G** terminal for continuous fan (without calling for heat or cooling), the indoor fan is energized on the selected FAN speed.
- If a call for cooling occurs during continuous fan, the blower will switch over to the selected COOL speed.
- If the **W** terminal receives a call for heat during continuous fan, the blower will de energize.
- A call for fan is ignored while in lockout.

## MAINTENANCE

Proper maintenance is most important to achieve the best performance from a furnace. Follow these instructions for years of safe, trouble free operation.

### **WARNING:**

#### **ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD**

**Failure to follow safety warnings exactly could result in serious injury or property damage.**

**Improper servicing could result in dangerous operation, serious injury, death or property damage.**

- **Before servicing, disconnect all electrical power to furnace.**
- **When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.**
- **Verify proper operation after servicing.**

### **AVERTISSEMENT :**

#### **RISQUE DE DÉCHARGE ÉLECTRIQUE, D'INCENDIE OU D'EXPLOSION**

**Le non-respect des avertissements de sécurité pourrait entraîner des blessures graves ou des dommages matériels.**

**Un entretien inapproprié peut provoquer un fonctionnement dangereux, des blessures graves, la mort ou des dommages matériels.**

- **Avant toute intervention, couper l'alimentation électrique du générateur d'air chaud.**
- **Pour l'entretien des commandes, étiqueter tous les fils avant de les débrancher. Rebrancher les fils correctement.**
- **Vérifier le bon fonctionnement après l'intervention.**

- These maintenance instructions are primarily intended to assist qualified technicians experienced in the proper maintenance and operation of this appliance.
- Always close the door on the furnace after servicing or cleaning/changing the filters. **Do not operate the furnace without the door closed.**
- Verify the thermostat is properly installed and will not be affected by drafts or heat from lamps or other appliances.
- To achieve the best performance and minimize equipment failure it is recommended that a yearly maintenance checkup be performed. At a minimum, this check should include the following items:

## Air Filter(s)

---

### **WARNING:**

**Never operate the furnace without a filter in place. Dust and lint can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.**

---

An air filter is supplied with the furnace as shipped from the factory. Filters should be changed or cleaned monthly during the heating season. Newly built or renovated homes may require more frequent changing until the construction dust has minimized.

Filters designed to remove smaller particles such as pollen, may require additional maintenance.

### **Blower Compartment**

Dirt and lint can create excessive loads on the motor resulting in higher than normal operating temperatures and shortened service life. It is recommended that the blower compartment be cleaned of dirt or lint that may have accumulated in the compartment or on the blower and motor as part of the annual inspection.

### **Cleaning of Burners**

If the burners must be cleaned, follow steps 1-12. See Figure 17 (page 27) for component location.

1. Shut off gas supply to the furnace at the meter or at a manual valve in the supply piping.
  2. Turn off all power to the furnace and set the thermostat to it's lowest setting.
  3. Turn the gas control knob to the OFF position. See Figure 13 (page 18).
  4. Disconnect the wires from the gas valve, igniter, flame sensor, and flame rollout switch.
- 

### **CAUTION:**

**To prevent damage to the unit or internal components, it is recommended that two wrenches be used when loosening or tightening nuts. Do not over tighten!**

---

5. Using two wrenches, separate the ground-joint union in the gas supply piping at the furnace.
6. Remove the piping between the gas valve and the ground-joint union. (If applicable).
7. Remove the burner box door (6 screws).
8. Remove 4 screws securing the manifold assembly to the burner box.

9. Remove 4 screws from the corners of the box and carefully remove the burner assembly from the furnace. **IMPORTANT: DO NOT damage the igniter while removing the burner assembly.**

10. Inspect the burners for accumulated dust or debris. If necessary carefully clean them with a soft wire brush and a vacuum cleaner. **IMPORTANT: DO NOT damage the igniter while cleaning the burner assembly.**

11. Replace all the parts in reverse order that they were removed.

12. Follow the lighting instructions found on the furnace door to return the furnace to operation. Verify proper operation after servicing.

## Vent System

---

### **WARNING:**

**Holes in the vent pipe or heat exchanger can cause combustion products to enter the home. Replace the vent pipe or heat exchanger if leaks are found. Failure to prevent the circulation of combustion products into the living space can create potentially hazardous conditions including carbon monoxide poisoning that could result in personal injury or death.**

---

Check the inlet pipe (if applicable) and outlet pipe to ensure they are not blocked by debris. Any damaged section of vent pipe must be replaced, and any obstruction or blockage must be removed prior to operating the furnace.

### **Heat Exchanger & Burner Maintenance**

The furnace should operate for many years without soot buildup in the flue passageways, however, the flue, vent system, and burners should be inspected and cleaned (if required) by a qualified service technician annually to ensure continued safe operation. Pay attention to any deterioration from corrosion or other sources.

### **Lubrication**

The bearings in the blower motor and inducer blower used in these furnaces are pre-lubricated and sealed by the manufacturer. No further oiling of the bearings is required for the life of the motor.

## TROUBLESHOOTING

If the furnace fails to operate check the following:

- Is the thermostat operating properly?
- Are the blower compartment door(s) in place?
- Is the furnace disconnect closed?
- Has the circuit breaker tripped or the control board fuse burned open?
- Is the gas turned on?
- Are any manual reset switches open?
- Is the filter dirty or plugged?
- Is the flame sensor coated? (Remove and clean with steel wool. **(Do not use emery cloth or sandpaper!)**)
- Is there blockage in the condensate drain switch? Also verify that there is no double trapping of condensate.
- Is the secondary heat exchanger free of debris and clogs?
- Is evaporator coil clean and free of debris (If applicable).
- Are all the LED's on the furnace control board constantly ON? If not, refer to Table 6 or the wiring diagram (Figure 18, page 29) to determine fault condition.

### IMPORTANT NOTE

The furnace will lock out after 5 failed attempts for ignition and will try again every hour if the call for heat remains.

- If the inducer blower is operating, and items above have been verified, check the blower limit switch and reset if necessary. See Figure 17 for component location.
- If the furnace operates when the Blower Limit Switch is reset, contact a qualified service technician to identify and repair the problem.
- If the furnace still doesn't operate, check the flame roll-out switch (Figure 17) and reset if necessary.
- If the furnace operates when the flame rollout switch is reset, contact a qualified service technician to identify and repair the problem.

| Diagnostic Description       | Green LED         | Red LED |
|------------------------------|-------------------|---------|
| Control Fault (No Power)     | Off               | Off     |
| L1/Neutral Polarity Fault    | Flash             | Flash   |
| 1 Hour Lockout               | Alternating Flash |         |
| Normal Operation             | On                | On      |
| Pressure Switch Closed Fault | On                | Flash   |
| Pressure Switch Open Fault   | Flash             | On      |
| Open Limit Switch Fault      | Flash             | Off     |
| Motor Fault                  | On                | Off     |
| Diagnostic Description       | Yellow LED        |         |
| Low Flame Sensor Signal      | Continuous Flash  |         |
| Flame Present                | On                |         |

Table 6. Control Board Fault Conditions

## FURNACE COMPONENTS

The descriptions below are various functional components that affect the operation and shutting down of this furnace. Some of these components and their locations are shown in Figure 17. If any component of the furnace must be replaced, use only factory authorized replacement parts specified in the Replacement Parts List provided online.

**Blower Limit Switch:** Prevents operation when blower is not operational.

**Flame Sensor:** Verifies when a flame has carried over from the igniter to the opposite end burner. If no flame is detected, the furnace will shut down within 4 seconds.

**Flame Roll-Out Switch:** Verifies that the burner flames are drawn into the heat exchanger tubes. If the burner flames are not properly drawn into the heat exchanger, the flame roll-out switch will close the gas valve and initiate the shutdown cycle.

**Gas Valve:** Controls the flow of gas to the burners. When the gas valve is energized it automatically opens and regulates the gas pressure in the manifold.

**Inducer Assembly:** Vents products of combustion to the outside.

**Pressure Switch:** Verifies that the inducer is drawing the combustion gases through the heat exchanger. The pressure switch prevents furnace operation with excessive flue/condensate blockage or improper inducer operation.

**Main Air Limit Switch:** Prevents the air temperature leaving the furnace from exceeding the maximum allowable outlet air temperature.





Figure 17. Furnace Components

## FIGURES & TABLES



**Figure 18. Furnace Dimensions**

# Electrical Diagrams & Data

## WIRING DIAGRAM


### For 80+ and 90+ Single Stage Furnaces

Refer to the Installation Instructions provided with the furnace for the proper heating and cooling speeds for your application.

| FAULT CONDITIONS             |                   |         |         |
|------------------------------|-------------------|---------|---------|
| Diagnostic Description       | Green LED         | Red LED | Red LED |
| Control Fault (No Power)     | Off               | Off     | Flash   |
| L1 / Neutral Polarity Fault  | Flash             | Flash   | Flash   |
| 1 Hour Lockout               | Alternating Flash | On      | Flash   |
| Normal Operation             | On                | On      | Flash   |
| Pressure Switch Closed Fault | On                | Flash   | Flash   |
| Pressure Switch Open Fault   | Flash             | Flash   | Flash   |
| Open Limit Switch Fault      | Flash             | Flash   | Flash   |
| Diagnostic Description       |                   |         |         |
| Low Flame Sensor Signal      | Continuous Flash  | On      | On      |
| Flame Present                | On                | On      | On      |

If any of the original wire as supplied with the furnace must be replaced, it must be replaced with wiring material having a temperature of at least 105° C.

Use copper conductors only.



LEGEND:  
 FIELD WIRING - - - - -  
 LOW VOLTAGE - - - - -  
 HIGH VOLTAGE - - - - -

1028603C  
 (Replaces 1028603B)  
 01/20

Figure 19. CMF95 Wiring Diagram

## Gas Information

| GAS FLOW RATES<br>(CUBIC FEET PER HOUR) |   |       |       |
|---|---|-------|-------|
| TIME FOR<br>ONE REVOLUTION<br>(SECONDS) | CUBIC FEET PER<br>REVOLUTION OF GAS METER |       |       |
|   | 1   | 5     | 10    |
| 10                                      | 360                                       | 1,800 | 3,600 |
| 12                                      | 300                                       | 1,500 | 3,000 |
| 14                                      | 257                                       | 1,286 | 2,571 |
| 16                                      | 225                                       | 1,125 | 2,250 |
| 18                                      | 200                                       | 1,000 | 2,000 |
| 20                                      | 180                                       | 900   | 1,800 |
| 22                                      | 164                                       | 818   | 1,636 |
| 24                                      | 150                                       | 750   | 1,500 |
| 26                                      | 138                                       | 692   | 1,385 |
| 28                                      | 129                                       | 643   | 1,286 |
| 30                                      | 120                                       | 600   | 1,200 |
| 32                                      | 113                                       | 563   | 1,125 |
| 34                                      | 106                                       | 529   | 1,059 |
| 36                                      | 100                                       | 500   | 1,000 |
| 38                                      | 95  | 474   | 947   |
| 40                                      | 90  | 450   | 900   |
| 42                                      | 86  | 429   | 857   |
| 44                                      | 82  | 409   | 818   |
| 46                                      | 78  | 391   | 783   |
| 48                                      | 75  | 375   | 750   |
| 50                                      | 72  | 360   | 720   |
| 52                                      | 69  | 346   | 692   |
| 54                                      | 67  | 333   | 667   |
| 56                                      | 64  | 321   | 643   |
| 58                                      | 62  | 310   | 621   |
| 60                                      | 60  | 300   | 600   |
| 62                                      | 58  | 290   | 581   |
| 64                                      | 56  | 281   | 563   |

| GAS FLOW RATES<br>(CUBIC FEET PER HOUR) |   |     |     |
|---|---|-----|-----|
| TIME FOR<br>ONE REVOLUTION<br>(SECONDS) | CUBIC FEET PER<br>REVOLUTION OF GAS METER |     |     |
|   | 1   | 5   | 10  |
| 66                                      | 55  | 273 | 545 |
| 68                                      | 53  | 265 | 529 |
| 70                                      | 51  | 257 | 514 |
| 72                                      | 50  | 250 | 500 |
| 74                                      | 49  | 243 | 486 |
| 76                                      | 47  | 237 | 474 |
| 78                                      | 46  | 231 | 462 |
| 80                                      | 45  | 225 | 450 |
| 82                                      | 44  | 220 | 439 |
| 84                                      | 43  | 214 | 429 |
| 86                                      | 42  | 209 | 419 |
| 88                                      | 41  | 205 | 409 |
| 90                                      | 40  | 200 | 400 |
| 92                                      | 39  | 196 | 391 |
| 94                                      | 38  | 191 | 383 |
| 96                                      | 38  | 188 | 375 |
| 98                                      | 37  | 184 | 367 |
| 100                                     | 36  | 180 | 360 |
| 102                                     | 35  | 176 | 353 |
| 104                                     | 35  | 173 | 346 |
| 106                                     | 34  | 170 | 340 |
| 108                                     | 33  | 167 | 333 |
| 110                                     | 33  | 164 | 327 |
| 112                                     | 32  | 161 | 321 |
| 114                                     | 32  | 158 | 316 |
| 116                                     | 31  | 155 | 310 |
| 118                                     | 31  | 153 | 305 |
| 120                                     | 30  | 150 | 300 |

**Table 7. Gas Flow Rates**

| CAPACITY OF BLACK IRON GAS PIPE (CU. FT. PER HOUR)<br>FOR NATURAL GAS (SPECIFIC GRAVITY - 0.60) |                           |       |     |     |     |     |     |     |
|---|---------------------------|-------|-----|-----|-----|-----|-----|-----|
| Nominal Pipe<br>Diameter (IN.)  | Length of Pipe Run (Feet) |       |     |     |     |     |     |     |
|   | 10                        | 20    | 30  | 40  | 50  | 60  | 70  | 80  |
| 1/2   | 130                       | 90    | 75  | 65  | 55  | 50  | 45  | 40  |
| 3/4   | 280                       | 190   | 150 | 130 | 115 | 105 | 95  | 90  |
| 1   | 520                       | 350   | 285 | 245 | 215 | 195 | 180 | 170 |
| 1 1/4   | 1,050                     | 730   | 590 | 500 | 440 | 400 | 370 | 350 |
| 1 1/2   | 1,600                     | 1,100 | 890 | 760 | 670 | 610 |     |     |

Cubic Feet Per Hour Required =  $\frac{\text{Input To Furnace (Btu/hr)}}{\text{Heating Value of Gas (Btu/Cu. Ft.)}}$

**NOTE:** The cubic feet per hour listed in the table above must be greater than the cubic feet per hour of gas flow required by the furnace. To determine the cubic feet per hour of gas flow required by the furnace, divide the input rate of the furnace by the heating value (from gas supplier) of the gas.

**Table 8. Gas Pipe Capacities**

| ORIFICES FOR PROPANE GAS<br>MANIFOLD PRESSURE = 10 in. W.C. |             |        |
|---|-------------|--------|
| ALTITUDE ABOVE SEA LEVEL                                    | INPUT (BTU) |        |
|   | 45,000      | 72,000 |
| 0 to 1,999 FT   | 57          | 56     |
| 2,000 to 2,999 FT   | 57          | 56     |
| 3,000 to 3,999 FT   | 57          | 56     |
| 4,000 to 4,999 FT   | 57          | 56     |
| 5,000 to 5,999 FT   | 58          | 56     |
| 6,000 to 6,999 FT   | 59          | 57     |
| 7,000 to 7,999 FT   | 59          | 57     |
| 8,000 to 8,999 FT   | 60          | 57     |
| 9,000 to 9,999 FT   | 61          | 57     |

**Table 9. Orifices for Propane Gas**

| LOCAL HEATING VALUES FOR NATURAL GAS |                    |     |      |      |      |      |      |       |       |
|--------------------------------------|--------------------|-----|------|------|------|------|------|-------|-------|
| ALTITUDE ABOVE SEA LEVEL             | BTU PER CUBIC FOOT |     |      |      |      |      |      |       |       |
|                                      | 650                | 700 | 750  | 800  | 850  | 900  | 950  | 1,000 | 1,050 |
| 2,000 FT                             | LOW                | LOW | LOW  | LOW  | LOW  | LOW  | HIGH | HIGH  | HIGH  |
| 3,000 FT                             | LOW                | LOW | LOW  | LOW  | LOW  | LOW  | HIGH | HIGH  | HIGH  |
| 4,000 FT                             | LOW                | LOW | LOW  | LOW  | LOW  | HIGH | HIGH | HIGH  | HIGH  |
| 5,000 FT                             | LOW                | LOW | LOW  | LOW  | LOW  | HIGH | HIGH | HIGH  | HIGH  |
| 6,000 FT                             | LOW                | LOW | LOW  | LOW  | HIGH | HIGH | HIGH | HIGH  | HIGH  |
| 7,000 FT                             | LOW                | LOW | LOW  | LOW  | HIGH | HIGH | HIGH | HIGH  | HIGH  |
| 8,000 FT                             | LOW                | LOW | LOW  | HIGH | HIGH | HIGH | HIGH | HIGH  | HIGH  |
| 9,000 FT                             | LOW                | LOW | LOW  | HIGH | HIGH | HIGH | HIGH | HIGH  | HIGH  |
| 10,000 FT                            | LOW                | LOW | HIGH | HIGH | HIGH | HIGH | HIGH | HIGH  | HIGH  |

**Table 10. Natural Gas Heating Values**


| HIGH HEATING VALUE &<br>MANIFOLD PRESSURE = 3.5 in. W.C. |             |        |
|--|-------------|--------|
| ALTITUDE ABOVE SEA LEVEL                                 | INPUT (BTU) |        |
|  | 45,000      | 72,000 |
| 0 to 1,999 FT  | 49          | 47     |
| 2,000 to 2,999 FT  | 50          | 48     |
| 3,000 to 3,999 FT  | 50          | 48     |
| 4,000 to 4,999 FT  | 51          | 48     |
| 5,000 to 5,999 FT  | 51          | 49     |
| 6,000 to 6,999 FT  | 51          | 49     |
| 7,000 to 7,999 FT  | 52          | 50     |
| 8,000 to 8,999 FT  | 52          | 50     |
| 9,000 to 9,999 FT  | 52          | 50     |

**Table 11. Orifices for Natural Gas  
High Heating Value**

| LOW HEATING VALUE &<br>MANIFOLD PRESSURE = 3.5 in. W.C. |             |        |
|---|-------------|--------|
| ALTITUDE ABOVE SEA LEVEL                                | INPUT (BTU) |        |
|   | 45,000      | 72,000 |
| 0 to 1,999 FT   | 49          | 47     |
| 2,000 to 2,999 FT                                       | 49          | 47     |
| 3,000 to 3,999 FT                                       | 49          | 47     |
| 4,000 to 4,999 FT                                       | 50          | 47     |
| 5,000 to 5,999 FT                                       | 50          | 47     |
| 6,000 to 6,999 FT                                       | 50          | 48     |
| 7,000 to 7,999 FT                                       | 51          | 48     |
| 8,000 to 8,999 FT                                       | 51          | 49     |
| 9,000 to 9,999 FT                                       | 51          | 49     |

**Table 12. Orifices for Natural Gas  
Low Heating Value**

## Venting Information



| Clearance Location | CANADIAN INSTALLATIONS <sup>a</sup>  | US INSTALLATIONS <sup>b</sup>   |   |
|--------------------|--|---|---|
|                    | Direct Vent (2-pipe) & Conventional Vent (1-pipe) Furnaces   | Direct Vent (2-pipe) Furnaces   | Conventional Vent (1-pipe) Furnaces                                   |
| A                  | 12 inches (30cm)   | 12 inches (30cm)  | 12 inches (30cm)  |
| B                  | 6 inches (15cm) for appliances < 10,000 Btuh (3kW)<br>12 inches (30cm) for appliances 10,000 Btuh - 100,000 Btuh (30kW)<br>36 inches (91cm) for appliances > 100,000 Btuh (30Kw) | 6 inches (15cm) for appliances < 10,000 Btuh (3kW)<br>9 inches (23cm) for appliances 10,000 Btuh - 50,000 Btuh (30kW)<br>12 inches (30cm) for appliances > 50,000 Btuh (30Kw) | 4 ft. (1.2m) below or to side of opening; 1 ft. (300mm) above opening |
| C                  | 12 inches (30cm) suggested or as needed to avoid condensation on glass.  | 12 inches (30cm) suggested or as needed to avoid condensation on glass.   |   |
| D                  | Clearance must be greater than the depth of the soffit unless it complies with Figure 20 (page 33)   | Clearance must be greater than the depth of the soffit unless it complies with Figure 20 (page 33)  |   |
| E                  | Clearance must be greater than the depth of the soffit unless it complies with Figure 20 (page 33)   | Clearance must be greater than the depth of the soffit unless it complies with Figure 20 (page 33)  |   |
| F                  | All Clearances in this Figure apply on both walls  | All Clearances in this Figure apply on both walls   |   |
| G                  | All Clearances in this Figure apply on both walls  | All Clearances in this Figure apply on both walls   |   |
| H                  | 3 feet (91cm) within a height 15 feet above the meter/regulator assembly   | 3 feet (91cm) within a height of 15 feet  |   |
| I                  | 3 feet (91cm)  | 3 feet (91cm) in any direction  |   |
| J                  | 6 inches (15cm) for appliances < 10,000 Btuh (3kW)<br>12 inches (30cm) for appliances 10,000 Btuh - 100,000 Btuh (30kW)<br>36 inches (91cm) for appliances > 100,000 Btuh (30Kw) | 6 inches (15cm) for appliances < 10,000 Btuh (3kW)<br>9 inches (23cm) for appliances 10,000 Btuh - 50,000 Btuh (30kW)<br>12 inches (30cm) for appliances > 50,000 Btuh (30Kw) | 4 ft. (1.2m) below or to side of opening; 1 ft. (300mm) above opening |
| K                  | 6 feet (1.83m)   | 3 feet (91cm) above if within 10 feet (3m) horizontally   | 3 ft. (91cm) above if within 10 feet (3m) horizontally                |
| L                  | 7 feet (2.13m) <sup>c</sup>  | 7 feet (2.13m) <sup>c</sup>   | 7 ft. (2.13m)   |
| M                  | 12 inches (30cm) <sup>d</sup>  | 12 inches (30cm) <sup>d</sup>   | 12 inches (30cm) <sup>d</sup>   |

**NOTES:**

a = In accordance with the current CSA B149.1 Natural Gas and Propane Installation Guide Code

b = In accordance with the current ANSI Z223.1 / NFPA 54 Natural Fuel Gas Code

c = A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.

d = Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

**Table 13. Vent Termination Clearances**




Figure 20. Horizontal & Vertical Venting





## INSTALLATION CHECKLIST

### ATTENTION INSTALLERS:

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation/service personnel for this type of equipment. Please read all instructions carefully before starting the installation. Return these instructions to the customer's package for future reference.

### INSTALLER NAME:

|  |        |    |
|--|--------|----|
| CITY:  | STATE: |    |
| <b>INSTALLATION ADDRESS:</b>                                   |        |    |
| CITY:  | STATE: |    |
| UNIT MODEL #   |        |    |
| UNIT SERIAL #  |        |    |
| Minimum clearances per Table 1 (page 5)?                       | YES    | NO |
| Has the owner's information been reviewed with the home-owner? | YES    | NO |
| Has the literature package been left near the furnace?         | YES    | NO |

### ELECTRICAL SYSTEM

|  |     |    |
|--|-----|----|
| Electrical connections tight?            | YES | NO |
| Line voltage polarity correct?           | YES | NO |
| Supply Voltage (VOLTS):                  |     |    |
| Has the thermostat been calibrated?      | YES | NO |
| Is the thermostat level?                 | YES | NO |
| Is the heat anticipator setting correct? | YES | NO |

### GAS SYSTEM

|                                   |             |         |
|-----------------------------------|-------------|---------|
| Gas Type: (circle one)            | Natural Gas | Propane |
| Gas pipe connections leak tested? | YES         | NO      |
| Gas Line Pressure (in - W.C.):    |             |         |
| Installation Altitude (FT.):      |             |         |
| Deration Percentage (%):          |             |         |
| Furnace Input (Btuh):             |             |         |
| Supply Air Temperature (° F):     |             |         |
| Return Air Temperature (° F):     |             |         |
| Temperature Rise (° F):           |             |         |

### COMBUSTION AIR & VENTING SYSTEM

|  |     |    |
|--|-----|----|
| Is there adequate fresh air supply for combustion and ventilation? | YES | NO |
| Vent free from restrictions?                                       | YES | NO |
| Filter(s) secured in place?  | YES | NO |
| Filter(s) clean?   | YES | NO |
| Flue connections tight?  | YES | NO |
| Is there proper draft?   | YES | NO |

