P3B*/Q3B* Series

Installation Instructions

Close-Off Plate Kit #903966 for Platinum Series Product Line

STEP #1
CLEAN SURFACE
USING ALCOHOL
PAD PROVIDED
(SHADED AREA)

STEP #2
REMOVE TAPE

STEP #3
ALIGN INSULATION INSIDE
OPENING AND PRESS FIRMLY
AROUND FULL PERIMETER
OF PART

STEP #4 (OPTIONAL)
APPLY CAULKING
AROUND FULL
PERIMETER OF
COVER PLATE