

# WIRING DIAGRAM


H3HK009H-01 (without circuit breaker)

9kW, 1-Stage, 240 VAC, 1-Phase Electric Heater Kit

H3HK015H-01 (without circuit breaker)

15kW, 1-Stage, 240 VAC, 1-Phase Electric Heater Kit

H3HK015H-21 (with circuit breaker)



## NOTES:

- 1) Circuit breakers are not wired to heater kit by the factory, see Installation Instructions for wiring procedure.
- 2) If any of the original wire supplied with this unit must be replaced, it must be replaced with wiring material of the same gauge size and temperature rating.
- 3) The installation of this heater kit may require a change in the blower speed tap connection. See Installation Instructions for details.
- 4) Use copper conductors with a minimum temperature rating of 60°C for supply connections.

FIELD WIRING	■■■■■■■■■■
FACTORY WIRING	_____
LOW VOLTAGE	_____
HIGH VOLTAGE	—————