

REPLACEMENT PARTS LIST

K & F Series

Single Stage Condensing & Non-Condensing Furnaces

NON-CONDENSING GAS FURNACES

80+ AFUE



***G7SA Upflow / Horizontal
Furnaces**



***G7SK Downflow
Furnaces**

CONDENSING GAS FURNACES

92.1% AFUE



***G7SC Upflow / Horizontal
Furnaces**



***G7SL Downflow
Furnaces**

95% AFUE



***G7SD Upflow /
Horizontal Furnaces**



***G7SM Downflow
Furnaces**

80+ AFUE

*G7SA Replacement Parts List - Upflow / Horizontal	2
*G7SK Replacement Parts List - Downflow	3
*G7SA-1 Replacement Parts List - Upflow / Horizontal	4
*G7SK-1 Replacement Parts List - Downflow	5
*G7SA / *G7SA-1 Component Location - Upflow / Horizontal	6
*G7SK / *G7SK-1 80+ Component Location - Downflow	7

92.1% & 95.0% AFUE

*G7SC Replacement Parts List - Upflow / Horizontal	8
*G7SL Replacement Parts List - Downflow	9
*G7SD Replacement Parts List - Upflow / Horizontal	10
*G7SM Replacement Parts List - Downflow	11
*G7SC-1 Replacement Parts List - Upflow / Horizontal	12
*G7SL-1 Replacement Parts List - Downflow	13
*G7SD-1 Replacement Parts List - Upflow / Horizontal	14
*G7SM-1 Replacement Parts List - Downflow	15
*G7SC / *G7SC-1 & *G7SD / *G7SD-1 Component Location - Upflow / Horizontal	16
*G7SL / *G7SL-1 & *G7SM / *G7SM-1 Component Location - Downflow	17

*G7SA REPLACEMENT PARTS LIST - UPFLOW / HORIZONTAL 80+ AFUE

ITEM	DESCRIPTION	045-23A	054-23A	072-24B	090-24B	072-35C	090-35C	108-35C	126-45D
1	Door Set	904767	904767	904768	904768	904769	904769	904769	904770
2	Top Panel	295911R	295911R	295912R	295912R	295913R	295913R	295913R	-
3	Collector Pan with gasket	904805	904812	904806	904807	-	904809	904810	904811
4	Inducer Motor	904796	904796	904796	904796	904796	904796	904796	904796
5	Inducer Gasket (Not Shown)	689988R	689988R	689988R	689988R	689988R	689988R	689988R	689988R
6	Transformer	622341R	622341R	622341R	622341R	622341R	622341R	622341R	622341R
7	Control Board	920915	920915	920915	920915	920915	920915	920915	920915
8	Fuse	632261R	632261R	632261R	632261R	632261R	632261R	632261R	632261R
9	Pressure Switch	632499R	632489R	632489R	632489R	632489R	632489R	632488R	632520R
10	Heat Exchanger	904779	904779	904780	904781	904782	904783	904868	904785
11	Main Air Limit	626614R	626614R	626612R	626613R	626615	626613R	626612R	626598R
12	Burner Assembly	904819	904820	904822	904824	904822	904824	904826	904828
13	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S
14	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R	299261R	299261R	299261R
15	Inshot Burner	661134R	661134R	661134R	661134R	661134R	661134R	661134R	661134R
16	Manifold, Burner Tube	664228R	664228R	664229R	664230R	664229R	664230R	664231RR	664232R
17	Orifice, Main Burner, Nat. Gas	661049R	661047R	661047R	661047R	661047R	661047R	661047R	661047R
18	Flame Sensor	632484R	632484R	632484R	632484R	632484R	632484R	632484R	632484R
19	Gas Valve	624775R	624775R	624775R	624775R	624775R	624775R	624775R	624775R
20	Roll-Out Switch	626610R	626610R	626610R	626610R	626610R	626609R	626610R	626610R
21	Door Switch	632125R	632125R	632125R	632125R	632125R	632125R	632125R	632125R
22	Blower Assembly	904681	904681	904682	904682	904683	904683	904684	904684
23	Blower Housing Assembly	297200R	297200R	297207R	297207R	297204R	297204R	297209R	297209R
24	Capacitor	01-0004	01-0004	01-0024	01-0024	01-0026	01-0026	01-0026	01-0026
25	Motor, Blower	904857	904857	904858	904858	904859	904859	904860	904860
26	Wheel, Blower	667251R	667251R	667258R	667258R	667207R	667207R	667280R	667280R
27	Blower Limit	626611R	626611R	626611R	626611R	626611R	626611R	626611R	626611R
28	Repl. Motor Mount Kit	N/A	N/A	904951	904951	904980	904980	904951	904951
29	Hose, High Temp (Not Shown)	263967R	263967R	263967R	263967R	263967R	263967R	263967R	263967R
30	Set of Wires (Not Shown)	M0036001R	M0036001R	M0036001R	M0036001R	M0036005R	M0036005R	M0036005R	M0036005R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

FOR COMPONENT LOCATIONS, SEE PAGE 6.

***G7SK REPLACEMENT PARTS LIST - DOWNFLOW**
80+ AFUE

ITEM	DESCRIPTION	054-23A	072-24B	090-24B	108-35C	126-45D
1	Door Set	904767	904768	904768	904769	904770
2	Top Panel	295911R	295912R	295912R	295913R	-
3	Collector Pan With Gasket	904901	904806	-	-	904811
4	Inducer Motor	904796	904796	904796	904796	904796
5	Inducer Gasket (Not Shown)	689988R	689988R	689988R	689988R	689988R
6	Combustion Tube	299291R	299291R	299291R	299291R	299291R
7	Transformer	622341R	622341R	622341R	622341R	622341R
8	Control Board	920915	920915	920915	920915	920915
9	Fuse	632261R	632261R	632261R	632261R	632261R
10	Pressure Switch	632488R	632489R	632489R	632488R	632488R
11	Heat Exchanger	904779	904780	904781	904868	904785
12	Main Air Limit	626601R	626601R	626617R	626616	626617R
13	Burner Assembly	904820	904822	904824	904826	904828
14	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S
15	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R
16	Inshot Burner	661134R	661134R	661134R	661134R	661134R
17	Manifold, Burner Tube	664228R	664229R	664230R	664231R	664232R
18	Orifice, Main Burner, Natural Gas	661047R	661047R	661047R	661047R	661047R
19	Flame Sensor	632484R	632484R	632484R	632484R	632484R
20	Gas Valve	624775R	624775R	624775R	624775R	624775R
21	Roll-out Switch	626610R	626610R	626610R	626609R	626609R
22	Door Switch	632125R	632125R	632125R	632125R	632125R
23	Blower Assembly	904681	904682	904682	904684	904684
24	Blower Housing Assembly	297200R	297207R	297207R	297209R	294209R
25	Capacitor	01-0004	626617RR	626617RR	01-0026	01-0026
26	Motor, Blower	904857	904858	904858	904860	904860
27	Wheel, Blower	667251R	667258R	667258R	667280R	667280R
28	Blower Limit	626611R	626611R	626611R	626611R	626611R
29	Repl. Motor Mount Kit	N/A	904951	904951	904951	904951
30	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R	263967R
31	Set of Wires (Not Shown)	M0036035R	M0036038R	M0036038R	M0036030R	M0036030R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

FOR COMPONENT LOCATIONS, SEE PAGE 7.

*G7SA-1 REPLACEMENT PARTS LIST - UPFLOW / HORIZONTAL 80+ AFUE

ITEM	DESCRIPTION	045-23A1	054-23A1	072-24B1	090-24B1	072-35C1	090-35C1	108-35C1	126-45D1
1	Door Set	904767	904767	904768	904768	904769	904769	904769	904770
2	Top Panel	295911R	295911R	295912R	295912R	295913R	295913R	295913R	-
3	Collector Pan with gasket	904805	904901	904998	904807	905016	904809	904810	905018
4	Inducer Motor	904999	904999	904999	904999	904999	904999	904999	904999
5	Inducer Gasket (Not Shown)	689988R	689988R	689988R	689988R	689988R	689988R	689988R	689988R
6	Transformer	622341R	622341R	622341R	622341R	622341R	622341R	622341R	622341R
7	Control Board	920915	920915	920915	920915	920915	920915	920915	920915
8	Fuse	632261R	632261R	632261R	632261R	632261R	632261R	632261R	632261R
9	Pressure Switch	632489R	632489R	632489R	632489R	632489R	632488R	632636R	632520R
10	Heat Exchanger	904779	904779	904780	904781	904782	904783	904868	904785
11	Main Air Limit	626614R	626601R	626612R	626613R	626616	626614R	626614R	626598R
12	Burner Assembly	904819	904820	904822	904824	904822	904824	904826	904828
13	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S
14	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R	299261R	299261R	299261R
15	Inshot Burner	661134R	661134R	661134R	661134R	661134R	661134R	661134R	661134R
16	Manifold, Burner Tube	664228R	664228R	664229R	664230R	664229R	664230R	664231R	664232R
17	Orifice, Main Burner, Nat. Gas	661049R	661047R	661047R	661047R	661047R	661047R	661047R	661047R
18	Flame Sensor	632484R	632484R	632484R	632484R	632484R	632484R	632484R	632484R
19	Gas Valve	624775R	624775R	624775R	624775R	624775R	624775R	624775R	624775R
20	Roll-Out Switch	626610R	626610R	626610R	626610R	626610R	626609R	626610R	626610R
21	Door Switch	632125R	632125R	632125R	632125R	632125R	632125R	632125R	632125R
22	Blower Assembly	904681	904681	904682	904682	904683	904683	904684	904684
23	Blower Housing Assembly	297200R	297200R	297207R	297207R	297204R	297204R	297209R	297209R
24	Capacitor	01-0024	01-0024	01-0024	01-0024	01-0026	01-0026	01-0026	01-0026
25	Motor, Blower	904857	904857	904858	904858	904859	904859	904860	904860
26	Wheel, Blower	667251R	667251R	667258R	667258R	667207R	667207R	667280R	667280R
27	Blower Limit	626611R	626611R	626611R	626611R	626611R	626611R	626611R	626611R
28	Repl. Motor Mount Kit	N/A	N/A	904951	904951	904980	904980	904951	904951
29	Hose, High Temp (Not Shown)	263967R	263967R	263967R	263967R	263967R	263967R	263967R	263967R
30	Set of Wires (Not Shown)	M0036001R	M0036001R	M0036001R	M0036001R	M0036005R	M0036005R	M0036005R	M0036005R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

FOR COMPONENT LOCATIONS, SEE PAGE 6.


***G7SK-1 REPLACEMENT PARTS LIST - DOWNFLOW**
80+ AFUE

ITEM	DESCRIPTION	054-23A1	072-24B1	090-24B1	108-35C1	126-45D1
1	Door Set	904767	904768	904768	904769	904770
2	Top Panel	295911R	295912R	295912R	295913R	-
3	Collector Pan With Gasket	904901	904806	904806	905017	05019
4	Inducer Motor	904999	904999	904999	904999	904999
5	Inducer Gasket (Not Shown)	689988R	689988R	689988R	689988R	689988R
6	Combustion Tube	299291R	299291R	299291R	299291R	299291R
7	Transformer	622341R	622341R	622341R	622341R	622341R
8	Control Board	920915	920915	920915	920915	920915
9	Fuse	632261R	632261R	632261R	632261R	632261R
10	Pressure Switch	632488R	632489R	632489R	632488R	632488R
11	Heat Exchanger	904779	904780	904781	904868	904785
12	Main Air Limit	626601R	626601R	626617R	626617R	626601R
13	Burner Assembly	904820	904822	904824	904826	904828
14	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S
15	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R
16	Inshot Burner	661134R	661134R	661134R	661134R	661134R
17	Manifold, Burner Tube	664228R	664229R	664230R	664231R	664232R
18	Orifice, Main Burner, Natural Gas	661047R	661047R	661047R	661047R	661047R
19	Flame Sensor	632484R	632484R	632484R	632484R	632484R
20	Gas Valve	624775R	624775R	624775R	624775R	624775R
21	Roll-out Switch	626610R	626610R	626610R	626609R	626609R
22	Door Switch	632125R	632125R	632125R	632125R	632125R
23	Blower Assembly	904681	904682	904682	904684	904684
24	Blower Housing Assembly	297200R	297207R	297207R	297209R	294209R
25	Capacitor	01-0024	626617RR	626617RR	01-0026	01-0026
26	Motor, Blower	904857	904858	904858	904860	904860
27	Wheel, Blower	667251R	667258R	667258R	667280R	667280R
28	Blower Limit	626611R	626611R	626611R	626611R	626611R
29	Repl. Motor Mount Kit	N/A	904951	904951	904951	904951
30	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R	263967R
31	Set of Wires (Not Shown)	M0036035R	M0036038R	M0036038R	M0036030R	M0036030R


Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

FOR COMPONENT LOCATIONS, SEE PAGE 7.

***G7SA / *G7SA-1 COMPONENT LOCATION - UPFLOW / HORIZONTAL**



***G7SK / *G7SK-1 80+ COMPONENT LOCATION - DOWNFLOW**



*G7SC REPLACEMENT PARTS LIST - UPFLOW / HORIZONTAL

92.1% AFUE

ITEM	DESCRIPTION	038D-23A & 038D-23A-1	054D-24B & 054D-24B-1	072D-24B & 072D-24B-1	072D-35C & 072D-35C-1	090D-35C & 090D-35C-1	108D-45D & 108D-45D-1	120D-45D & 120D-45D-1
1	Door Set	904767	904768	904768	904769	904769	904770	904770
2	Top Panel	2B3551R	2B3552R	2B3552R	2B3553R	2B3553R	2B3554R	2B3554R
3	Burner Assembly	904818	904821	904823	904823	904825	904827	-
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R	299261R	299261R
6	Inshot Burner	661134R	661134R	661134R	661134R	661134R	661134R	661134R
7	Manifold, Burner Tube	664237R	664238R	664239RR	664239R	664240R	664241R	664241R
8	Orifice, Main Burner, Nat. Gas	661045R	661047R	661047R	661047R	661047R	661047R	661045R
9	Flame Sensor	632484R	632484R	632484R	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626608	626608	626609R	626609R	626609R	626609R	626608
12	Control Board	920915	920915	920915	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R	632261R	632261R	632261R
14	Heat Exchanger	904786	904869	904788	904870	904871	904791	904791
15	Main Air Limit	626598R	626614R	626613R	626614R	626613R	626614R	626614R
16	Inducer Motor (*G7SC models only)	904798	904798	904798	904798	904798	904798	904798
17	Inducer Orifice	669719R	669712R	669713R	669715R	669717R	Not Used	Not Used
18	Inducer Limit	626599R	626599R	626599R	626599R	626599R	626599R	626599R
19	Outlet Header Box	904801	904802	904802	904803	904803	904804	904804
20	Pressure Switch (condensate)	632585R	632491R	632622R	632491R	632491R	632491R	632491R
21	Pressure Switch (inducer)		632487R	632495R	632493R	632493R	632493R	632493R
22	Transformer	622341R	622341R	622341R	622341R	622341R	622341R	622341R
23	Door Switch	632125R	632125R	632125R	632125R	632125R	632125R	632125R
24	Blower Assembly	904681	904682	904682	904683	904684	904684	904684
25	Blower Housing Assembly	297200R	294207R	297207R	297204R	297209R	297209R	297209R
26	Capacitor	01-0004	01-0024	01-0024	01-0026	01-0026	01-0026	01-0026
27	Motor, Blower	904857	904858	904858	904859	904860	904860	904860
28	Wheel, Blower	667251R	667258R	667258R	667207R	667280R	667280R	667280R
29	Blower Limit	626611R	626611R	626611R	626611R	626611R	626611R	626611R
30	Repl. Motor Mount Kit	N/A	904951	904951	904980	904951	904951	904951
31	In-Line Drain Assembly	664435R	664435R	664435R	664435R	664435R	664435R	664435R
32	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R	664434R	664434R	664434R
33	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R	663706R	663706R	663706R
34	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R	663707R	663707R	663707R
35	Tube, Soft, 6.5" (Not Shown)	663727R	663727R	663727R	663727R	663727R	663727R	663727R
36	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R	263967R	263967R	263967R
37	Set of Wires (Not Shown)	M0036009R	M0036003R	M0036003R	M0036007R	M0036007R	M0036007R	M0036007R
38	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R	664633R	664633R	664633R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SC models are equipped with FASCO brand inducer motors. *SC-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 16.

***G7SL REPLACEMENT PARTS LIST - DOWNFLOW**
92.1% AFUE

ITEM	DESCRIPTION	054D-24B & 054D-24B-1	072D-24B & 072D-24B-1	090D-35C & 090D-35C-1	120D-45D & 120D-45D-1
1	Door Set	904768	904768	904769	904770
2	Top Panel	2B3562R	2B3562R	2B3563R	-
3	Burner Assembly	904821	904823	904825	904997
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R
6	Inshot Burner	661134R	661134R	661134R	661134R
7	Manifold, Burner Tube	664238R	664239R	664240R	664241R
8	Orifice, Main Burner, Natural Gas	661047R	661047R	661047R	661045R
9	Flame Sensor	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626609R	626610R	626610R	626610R
12	Control Board	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R
14	Heat Exchanger	904869	904788	904871	904791
15	Main Air Limit	626598R	626598R	626613R	626598R
16	Inducer Motor (*G7SL models only)	904798	904798	904798	904798
17	Inducer Orifice	669712R	669713R	669714R	Not Used
18	Inducer Limit	626599R	626599R	626599R	626599R
19	Outlet Header Box	904802	904802	904803	904804
20	Pressure Switch (inducer)	632487R	632487R	632487R	632487R
21	Transformer	622341R	622341R	622341R	622341R
22	Door Switch	632125R	632125R	632125R	632125R
23	Blower Assembly	904682	904682	904684	904684
24	Blower Housing Assembly	297207R	297207R	297209R	297209R
25	Capacitor	01-0024	01-0024	01-0026	01-0026
26	Motor, Blower	904858	904858	904860	904860
27	Wheel, Blower	667258R	667258R	667280R	667280R
28	Blower Limit/Blower Deck Limit	626611R	626611R	626611R	626611R
29	Repl. Motor Mount Kit	904951	904951	904951	904951
30	In-Line Drain Assembly	664435R	664435R	664435R	664435R
31	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R
32	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R
33	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R
34	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R
35	Set of Wires (Not Shown)	M0036004R	M0036004R	M0036029R	M0036029R
36	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SL models are equipped with FASCO brand inducer motors. *SL-1 models are equipped with Broad Ocean brand inducer motors.

[FOR COMPONENT LOCATIONS, SEE PAGE 17.](#)

***G7SD REPLACEMENT PARTS LIST - UPFLOW / HORIZONTAL**
95.0 % AFUE

ITEM	DESCRIPTION	038D-24B & 038D-24B-1	054D-24B & 054D-24B-1	072D-35C & 072D-35C-1	090D-35C & 090D-35C-1	108D-45D & 108D-45D-1	120D-45D & 120D-45D-1
1	Door Set	904768	904768	904769	904769	904770	904770
2	Top Panel	2A9512R	2A9512R	2A9513R	2A9513R	2A9514R	2A9514R
3	Burner Assembly	905020	905021	905022	905023	905024	905025
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R	299261R
6	Inshot Burner	661128R	661128R	661128R	661128R	661128R	661128R
7	Manifold, Burner Tube	664473R	664473R	664243R	664244R	664245	664245
8	Orifice, Main Burner, Nat. Gas	661051R	661047R	661047R	661047R	661046RR	661045R
9	Flame Sensor	632484R	632484R	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626609R	626610R	626610R	626610R	626610R	626610R
12	Control Board	920915	920915	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R	632261R	632261R
14	Heat Exchanger	904792	904792	904793	904794	904795	904795
15	Main Air Limit	626446R	626598R	626598R	626612R	626612R	626612R
16	Inducer Motor	904798	904798	904798	904798	904798	904798
17	Inducer Orifice	669927R	669718R	669719R	669734R	669715R	669717R
18	Inducer Limit	626599R	626599R	626599R	626599R	626599R	626599R
19	Outlet Header Box	904802	904802	904803	904803	904804	904804
20	Pressure Switch (Condensate)	632674R	632493R	632493R	632624R	632445R	632622R
21	Pressure Switch (Inducer)	632673R	632487R	632487R	632487R	632675R	632571R
22	Transformer	622341R	622341R	622341R	622341R	622341R	622341R
23	Door Switch	632125R	632125R	632125R	632125R	632125R	632125R
24	Blower Assembly	904682	904682	904683	904684	904684	904684
25	Blower Housing Assembly	294207R	294207R	297204R	297209R	297209R	297209R
26	Capacitor	01-0024	01-0024	01-0026	01-0026	01-0026	01-0026
27	Motor, Blower	904858	904858	904859	904860	904860	904860
28	Wheel, Blower	667258R	667258R	667207R	667280R	667280R	667280R
29	Blower Limit	626611R	626611R	626611R	626611R	626611R	626611R
30	Repl. Motor Mount Kit	904951	904951	904980	904951	904951	904951
31	In-Line Drain Assembly	664435R	664435R	664435R	664435R	664435R	664435R
32	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R	664434R	664434R
33	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R	663706R	663706R
34	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R	663707R	663707R
35	Tube, Soft, 6.5" (Not Shown)	663727R	663727R	663727R	663727R	663727R	663727R
36	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R	263967R	263967R
37	Set of Wires (Not Shown)	M0036003R	M0036003R	M0036007R	M0036007R	M0036007R	M0036007R
38	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R	664633R	664633R
39	PVC Trap (Not Shown)	664969R	664969R	664969R	664969R	664969R	664969R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SD models are equipped with FASCO brand inducer motors. *SD-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 16.

***G7SM REPLACEMENT PARTS LIST - DOWNFLOW**
95.0% AFUE

ITEM	DESCRIPTION	054D-24B & 054D-24B-1	072D-35C & 072D-35C-1	090D-35C & 090D-35C-1	118D-45D & 118D-45D-1
1	Door Set	904768	904769	904769	904770
2	Top Panel	2B3562R	2B3563R	2B3563R	-
3	Burner Assembly	905026	905022	905023	905027
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R
6	Inshot Burner	661128R	661128R	661128R	661128R
7	Manifold, Burner Tube	664611R	664243R	664244R	664245
8	Orifice, Main Burner, Natural Gas	661047R	661047R	661047R	661046R
9	Flame Sensor	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626610R	626610R	626610R	626610R
12	Control Board	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R
14	Heat Exchanger	904869	904788	904871	904791
15	Main Air Limit	626601R	626617R	626613R	626613R
16	Inducer Motor	904798	904798	904798	904798
17	Inducer Orifice	669718R	669719R	669734R	669717R
18	Inducer Limit	626599R	626599R	626599R	626599R
19	Outlet Header Box	904802	904803	904803	904804
20	Pressure Switch (Inducer)	632487R	632487R	632487R	632571R
21	Transformer	622341R	622341R	622341R	622341R
22	Door Switch	632125R	632125R	632125R	632125R
23	Blower Assembly	904682	904684	904684	904684
24	Blower Housing Assembly	297207R	297209R	297209R	297209R
25	Capacitor	01-0024	01-0026	01-0026	01-0026
26	Motor, Blower	904858	904860	904860	904860
27	Wheel, Blower	667258R	667280R	667280R	667280R
28	Blower Limit/Blower Deck Limit	626611R	626611R	626611R	626611R
29	Repl. Motor Mount Kit	904951	904951	904951	904951
30	In-Line Drain Assembly	664435R	664435R	664435R	664435R
31	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R
32	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R
33	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R
34	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R
35	Set of Wires (Not Shown)	M0036004R	M0036029R	M0036029R	M0036029R
36	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SM models are equipped with FASCO brand inducer motors. *SM-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 17.

*G7SC-1 REPLACEMENT PARTS LIST - UPFLOW / HORIZONTAL

92.1% AFUE

ITEM	DESCRIPTION	038D-23A & 038D-23A-1	054D-24B & 054D-24B-1	072D-24B & 072D-24B-1	072D-35C & 072D-35C-1	090D-35C & 090D-35C-1	108D-45D & 108D-45D-1	120D-45D & 120D-45D-1
1	Door Set	904767	904768	904768	904769	904769	904770	904770
2	Top Panel	2B3551R	2B3552R	2B3552R	2B3553R	2B3553R	2B3554R	2B3554R
3	Burner Assembly	904818	904821	904823	904823	904825	904827	-
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R	299261R	299261R
6	Inshot Burner	661134R	661134R	661134R	661134R	661134R	661134R	661134R
7	Manifold, Burner Tube	664237R	664238R	664239R	664239R	664240R	664241R	664241R
8	Orifice, Main Burner, Nat. Gas	661045R	661047R	661047R	661047R	661047R	661047R	661045R
9	Flame Sensor	632484R	632484R	632484R	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626608	626608	626609R	626609R	626609R	626609R	626608
12	Control Board	920915	920915	920915	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R	632261R	632261R	632261R
14	Heat Exchanger	904786	904869	904788	904870	904871	904791	904791
15	Main Air Limit	626598R	626614R	626613R	626614R	626613R	626614R	626614R
16	Inducer Motor	1003441	1003441	1003441	1003441	1003441	1003441	1003441
17	Inducer Orifice	669719R	669712R	669713R	669715R	669717R	Not Used	Not Used
18	Inducer Limit	626599R	626599R	626599R	626599R	626599R	626599R	626599R
19	Outlet Header Box	904801	904802	904802	904803	904803	904804	904804
20	Pressure Switch (condensate)	632585R	632491R	632622R	632491R	632491R	632491R	632491R
21	Pressure Switch (inducer)		632487R	632495R	632493R	632493R	632493R	632493R
22	Transformer	622341R	622341R	622341R	622341R	622341R	622341R	622341R
23	Door Switch	632125R	632125R	632125R	632125R	632125R	632125R	632125R
24	Blower Assembly	904681	904682	904682	904683	904684	904684	904684
25	Blower Housing Assembly	297200R	294207R	297207R	297204R	297209R	297209R	297209R
26	Capacitor	01-0004	01-0024	01-0024	01-0026	01-0026	01-0026	01-0026
27	Motor, Blower	904857	904858	904858	904859	904860	904860	904860
28	Wheel, Blower	667251R	667258R	667258R	667207R	667280R	667280R	667280R
29	Blower Limit	626611R	626611R	626611R	626611R	626611R	626611R	626611R
30	Repl. Motor Mount Kit	N/A	904951	904951	904980	904951	904951	904951
31	In-Line Drain Assembly	664435R	664435R	664435R	664435R	664435R	664435R	664435R
32	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R	664434R	664434R	664434R
33	Drain Tube, Hard "J"(Not Shown)	663706R	663706R	663706R	663706R	663706R	663706R	663706R
34	Drain Tube, Soft, "J" 30"(Not Shown)	663707R	663707R	663707R	663707R	663707R	663707R	663707R
35	Tube, Soft, 6.5" (Not Shown)	663727R	663727R	663727R	663727R	663727R	663727R	663727R
36	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R	263967R	263967R	263967R
37	Set of Wires (Not Shown)	M0036009R	M0036003R	M0036003R	M0036007R	M0036007R	M0036007R	M0036007R
38	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R	664633R	664633R	664633R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SC models are equipped with FASCO brand inducer motors. *SC-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 16.

***G7SL-1 REPLACEMENT PARTS LIST - DOWNFLOW**
92.1% AFUE

ITEM	DESCRIPTION	054D-24B & 054D-24B-1	072D-24B & 072D-24B-1	090D-35C & 090D-35C-1	120D-45D & 120D-45D-1
1	Door Set	904768	904768	904769	904770
2	Top Panel	2B3562R	2B3562R	2B3563R	-
3	Burner Assembly	904821	904823	904825	904997
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R
6	Inshot Burner	661134R	661134R	661134R	661134R
7	Manifold, Burner Tube	664238R	664239R	664240R	664241R
8	Orifice, Main Burner, Natural Gas	661047R	661047R	661047R	661045R
9	Flame Sensor	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626609R	626610R	626610R	626610R
12	Control Board	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R
14	Heat Exchanger	904869	904788	904871	904791
15	Main Air Limit	626598R	626598R	626613R	626598R
16	Inducer Motor	1003441	1003441	1003441	1003441
17	Inducer Orifice	669712R	669713R	669714R	Not Used
18	Inducer Limit	626599R	626599R	626599R	626599R
19	Outlet Header Box	904802	904802	904803	904804
20	Pressure Switch (inducer)	632487R	632487R	632487R	632487R
21	Transformer	622341R	622341R	622341R	622341R
22	Door Switch	632125R	632125R	632125R	632125R
23	Blower Assembly	904682	904682	904684	904684
24	Blower Housing Assembly	297207R	297207R	297209R	297209R
25	Capacitor	01-0024	01-0024	01-0026	01-0026
26	Motor, Blower	904858	904858	904860	904860
27	Wheel, Blower	667258R	667258R	667280R	667280R
28	Blower Limit/Blower Deck Limit	626611R	626611R	626611R	626611R
29	Repl. Motor Mount Kit	904951	904951	904951	904951
30	In-Line Drain Assembly	664435R	664435R	664435R	664435R
31	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R
32	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R
33	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R
34	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R
35	Set of Wires (Not Shown)	M0036004R	M0036004R	M0036029R	M0036029R
36	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SL models are equipped with FASCO brand inducer motors. *SL-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 17.

***G7SD-1 REPLACEMENT PARTS LIST - UPFLOW / HORIZONTAL**
95.0 % AFUE

ITEM	DESCRIPTION	038D-24B & 038D-24B-1	054D-24B & 054D-24B-1	072D-35C & 072D-35C-1	090D-35C & 090D-35C-1	108D-45D & 108D-45D-1	120D-45D & 120D-45D-1
1	Door Set	904768	904768	904769	904769	904770	904770
2	Top Panel	2A9512R	2A9512R	2A9513R	2A9513R	2A9514R	2A9514R
3	Burner Assembly	905020	905021	905022	905023	905024	905025
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R	299261R	299261R
6	Inshot Burner	661128R	661128R	661128R	661128R	661128R	661128R
7	Manifold, Burner Tube	664473R	664473R	664243R	664244R	664245	664245
8	Orifice, Main Burner, Nat. Gas	661051R	661047R	661047R	661047R	661046R	661045R
9	Flame Sensor	632484R	632484R	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626609R	626610R	626610R	626610R	626610R	626610R
12	Control Board	920915	920915	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R	632261R	632261R
14	Heat Exchanger	904792	904792	904793	904794	904795	904795
15	Main Air Limit	626446R	626598R	626598R	626612R	626612R	626612R
16	Inducer Motor	1003441	1003441	1003441	1003441	1003441	1003441
17	Inducer Orifice	669927R	669718R	669719R	669734R	669715R	669717R
18	Inducer Limit	626599R	626599R	626599R	626599R	626599R	626599R
19	Outlet Header Box	904802	904802	904803	904803	904804	904804
20	Pressure Switch (Condensate)	632674R	632493R	632493R	632624R	632445R	632622R
21	Pressure Switch (Inducer)	632673R	632487R	632487R	632487R	632675R	632571R
22	Transformer	622341R	622341R	622341R	622341R	622341R	622341R
23	Door Switch	632125R	632125R	632125R	632125R	632125R	632125R
24	Blower Assembly	904682	904682	904683	904684	904684	904684
25	Blower Housing Assembly	294207R	294207R	297204R	297209R	297209R	297209R
26	Capacitor	01-0024	01-0024	01-0026	01-0026	01-0026	01-0026
27	Motor, Blower	904858	904858	904859	904860	904860	904860
28	Wheel, Blower	667258R	667258R	667207R	667280R	667280R	667280R
29	Blower Limit	626611R	626611R	626611R	626611R	626611R	626611R
30	Repl. Motor Mount Kit	904951	904951	904980	904951	904951	904951
31	In-Line Drain Assembly	664435R	664435R	664435R	664435R	664435R	664435R
32	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R	664434R	664434R
33	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R	663706R	663706R
34	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R	663707R	663707R
35	Tube, Soft, 6.5" (Not Shown)	663727R	663727R	663727R	663727R	663727R	663727R
36	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R	263967R	263967R
37	Set of Wires (Not Shown)	M0036003R	M0036003R	M0036007R	M0036007R	M0036007R	M0036007R
38	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R	664633R	664633R
39	PVC Trap (Not Shown)	664969R	664969R	664969R	664969R	664969R	664969R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SD models are equipped with FASCO brand inducer motors. *SD-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 16.

***G7SM-1 REPLACEMENT PARTS LIST - DOWNFLOW**
95.0% AFUE


ITEM	DESCRIPTION	054D-24B & 054D-24B-1	072D-35C & 072D-35C-1	090D-35C & 090D-35C-1	118D-45D & 118D-45D-1
1	Door Set	904768	904769	904769	904770
2	Top Panel	2B3562R	2B3563R	2B3563R	-
3	Burner Assembly	905026	905022	905023	905027
4	Ignitor Assembly - Nitride	1017743S	1017743S	1017743S	1017743S
5	Igniter Bracket (Not Shown)	299261R	299261R	299261R	299261R
6	Inshot Burner	661128R	661128R	661128R	661128R
7	Manifold, Burner Tube	664611R	664243R	664244R	664245
8	Orifice, Main Burner, Natural Gas	661047R	661047R	661047R	661046R
9	Flame Sensor	632484R	632484R	632484R	632484R
10	Gas Valve	624775R	624775R	624775R	624775R
11	Roll-Out Switch	626610R	626610R	626610R	626610R
12	Control Board	920915	920915	920915	920915
13	Fuse	632261R	632261R	632261R	632261R
14	Heat Exchanger	904869	904788	904871	904791
15	Main Air Limit	626601R	626617R	626613R	626613R
16	Inducer Motor	1003441	1003441	1003441	1003441
17	Inducer Orifice	669718R	669719R	669734R	669717R
18	Inducer Limit	626599R	626599R	626599R	626599R
19	Outlet Header Box	904802	904803	904803	904804
20	Pressure Switch (Inducer)	632487R	632487R	632487R	632571R
21	Transformer	622341R	622341R	622341R	622341R
22	Door Switch	632125R	632125R	632125R	632125R
23	Blower Assembly	904682	904684	904684	904684
24	Blower Housing Assembly	297207R	297209R	297209R	297209R
25	Capacitor	01-0024	01-0026	01-0026	01-0026
26	Motor, Blower	904858	904860	904860	904860
27	Wheel, Blower	667258R	667280R	667280R	667280R
28	Blower Limit/Blower Deck Limit	626611R	626611R	626611R	626611R
29	Repl. Motor Mount Kit	904951	904951	904951	904951
30	In-Line Drain Assembly	664435R	664435R	664435R	664435R
31	Drain Tube, Soft, 23" (Not Shown)	664434R	664434R	664434R	664434R
32	Drain Tube, Hard "J" (Not Shown)	663706R	663706R	663706R	663706R
33	Drain Tube, Soft, "J" 30" (Not Shown)	663707R	663707R	663707R	663707R
34	Hose, High Temperature (Not Shown)	263967R	263967R	263967R	263967R
35	Set of Wires (Not Shown)	M0036004R	M0036029R	M0036029R	M0036029R
36	Finish Flange, Inlet Air	664633R	664633R	664633R	664633R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

*SM models are equipped with FASCO brand inducer motors. *SM-1 models are equipped with Broad Ocean brand inducer motors.

FOR COMPONENT LOCATIONS, SEE PAGE 17.

***G7SC / *G7SC-1 & *G7SD / *G7SD-1 COMPONENT LOCATION - UPFLOW / HORIZONTAL**



***G7SL / *G7SL-1 & *G7SM / *G7SM-1 COMPONENT LOCATION - DOWNFLOW**

