User's Information and Installation Instructions

Inducer Orifice Selection

Refer to the tables below to select the appropriate orifice size for this replacement kit. The orifice size can be found on the back side of each orifice.

Upflow/Horizontal Units:

Cabinet Size	Input (MBTUH)	Orifice Size (inches)
A	38	0.69
В	46	0.94
В	54	0.94
В	60	0.88(TC) / 1.00(MQ)
В	61	1.00
В	72	1.00
С	72	1.16
С	76	1.38
С	80	1.00
С	90	1.38
С	100	1.25
D	ALL	Not Used*

Downflow Units:

Cabinet Size	Input (MBTUH)	Orifice Size (inches)
В	54	0.94
В	60	0.75
В	72	1.00
С	80	0.97
С	90	1.13
С	100	1.31
D	120 (Two Stage)	1.50*





708925A (Replaces 7089250)

Specifications and illustrations subject to change without notice and without incurring obligations.

Printed in U.S.A. (10/08)

^{*}Note: Only the two stage, downflow D cabinet gets an inducer orifice. All other D cabinet units receive no inducer orifice.