


REPLACEMENT PARTS LIST

DT4QD Series 13 SEER Manufactured Housing Split System Heat Pump



DT4QD Series 13 SEER Split System Heat Pump

ITEM	DESCRIPTION	018K	024K	030K	036K	042K	048K	060K
2	Compressor	918867	918868	918869	918870	918871	918872	918873
3	Reversing Valve	669465	669465	669465	669466	669466	669466	669466
4	Muffler	669546	669546	669546	669546	669546	669546	669546
5	Service Valve	663621	663621	663621	663621	663621	663621	663621
6	Refrigerant Valve (Large)	664478	664478	664478	664479	664479	664479	664479
7	Refrigerant Valve (Small)	664477	664477	664477	664477	664477	664477	664477
8	Accumulator	668853	668853	668853	668794	668854	668854	668854
9	Distributor Assembly (not shown)	663578	663579	663579	663581	663582	663584	663584
10	Reversing Valve Coil Assembly	669470	669470	669470	669470	669470	669470	669470
11	Coil Guard (Formed)	275693R	275694R	275695R	275696R	275695R	275696R	275696R
12	Outdoor Coil (Formed)	499539R	499532R	499533R	499534R	499535R	917364	917364
13	Defrost Sensor (not shown)	626491	626491	626491	626491	626491	626491	626491
14	Control Box	277361	277361	277361	277361	277361	277361	277361
15	Low Voltage Divider	258791	258791	258791	258791	258791	258791	258791
16	Contacto	621661	621661	621661	621661	621662	621662	621662
17	Capacitor	620777	620762	620763	621635	621153	621644	621717
18	Capacitor strap	258781	258781	258781	258780	258780	258780	258780
19	Defrost Control Board	917178	917178	917178	917178	917178	917178	917178
20	Access Panel	274013	274014	274015	274016	274015	274016	274016
21	Top Pan	496162	496162	496162	496162	496162	496162	496162
22	Fan Motor	622080	622080	622080	622080	621990	621990	621990
23	Fan Blade	667316	667316	667316	667316	667316	667316	667316
24	Nut, Double thick	606260	606260	606260	606260	606260	606260	606260
25	Motor wire conduit	664162	664162	664162	664162	664162	664162	664162
26	Fan Grille	669202	669202	669202	669202	669202	669202	669202
27	Control Box Cover	276921	276921	276921	276921	276921	276921	276921
29	Grommet, Compressor (not shown)	668530	668530	668530	668530	668530	668530	668530
30	Bolt, Compressor	600426	600426	600426	600426	600426	600426	600426
31	High Press Switch (not shown)	632473	632473	632473	632473	632473	632473	632473
32	Filter Drier, Biflow (not shown)	669751	669751	669751	669751	669751	669751	669751
33	Connector, Swivel	663394	663394	663394	663394	663394	663394	663394
34	Restrictor, Outdoor Coil (not shown)	664042	664045	664048	664050	644055	664058	664062
35	Charge compensator (not shown)	-	-	-	-	669422	669422	669422
36	Compressor crankcase heater (not shown)	632410	632410	632410	632410	632410	632410	632410
37	Compressor molded plug (not shown)	634658	634658	634659	634659	634659	634660	634660
38	Outdoor Sensor (not shown)	626520	626520	626520	626520	626520	626520	626520
39	Restrictor, Indoor (not shown)	664050	664055	664065	664073	664077	664080	664089
40	Flange, coupling Mount (large)	663011	663011	663011	663011	663011	663011	663011
41	Flange, Coupling Mount (small)	663012	663012	663012	663012	663012	663012	663012

Specify Model No. and Serial No. along with the exact part number(s) when ordering parts from the nearest authorized Dealer or Service Center.

