


REPLACEMENT PARTS LIST

SPLIT SYSTEM HEAT PUMP WITH MICROCHANNEL COIL

JT4QE SERIES

14 SEER MODELS

ITEM #	COMPONENT
1	COMPRESSOR
2	REFRIGERANT VALVE (LG)
3	REFRIGERANT VALVE (SM)
4	MUFFLER
5	REVERSING VALVE COIL
6	REVERSING VALVE
7	ACCUMULATOR
8	DEFROST BOARD
9	CAPACITOR
10	OUTDOOR FAN MOTOR
11	OUTDOOR FAN GRILLE
12	TOP PAN
13	OUTDOOR FAN BLADE
14	OUTDOOR COIL
15	CONTACTOR
16	HOT GAS BYPASS SOLENOID



JT4QE SERIES SPLIT SYSTEM HEAT PUMP

COMPONENT	JT4QE-024KA	JT4QE-030KA	JT4QE-036KA	JT4QE-042KA	JT4QE-048KA
	922536J	922537J	922538J	922539J	922540J
ACCUMULATOR	668853R	668853R	668794R	668854R	668854R
AMBIENT SENSOR	624780	624780	624780	624780	624780
CAPACITOR	01-0083	01-0084	01-0085	01-0273	01-0271
COMPRESSOR	921422	921424	921426	921463	921465
COMPRESSOR MOLDED PLUG	634659R	634659R	634659R	634659R	634660R
CONTACTOR	624826	624826	624826	624827	624827
CRANKCASE HEATER	632410R	632410R	632410R	632410R	632410R
DEFROST BOARD	624813	624813	624813	624813	624813
DEFROST SENSOR	624812R	624812R	624812R	624812R	624812R
DISTRIBUTOR	664588R	664588R	664588R	664588R	664588R
FILTER DRIER	669762	669762	669762	669761	669761
HIGH PRESSURE SWITCH	632473R	632473R	632473R	632473R	632473R
HOT GAS BYPASS COIL	669992	669992	669992	669992	669992
HOT GAS BYPASS VALVE	669964	669964	669964	669964	669964
MUFFLER	669546R	669546R	669546R	669546R	669546R
OUTDOOR COIL	664905R	664906R	664907R	664908R	664908R
OUTDOOR COIL GUARD	2B6603R	2B6605R	2B6606R	2B6606R	2B6606R
OUTDOOR FAN BLADE	667383	667383	667383	667383	667383
OUTDOOR FAN GRILLE	669335R	669335R	669335R	669335R	669335R
OUTDOOR FAN MOTOR	622171R	622171R	622080R	621990R	621990R
REFRIGERANT VALVE (LG)	664478	664478	664479	664479	664479
REFRIGERANT VALVE (SM)	664477	664477	664477	664477	664477
REVERSING VALVE	669465R	669465R	M0079102	M0079102	M0079102
REVERSING VALVE COIL	669470R	669470R	669937R	669937R	669937R
SWIVEL NUT CONNECTOR	664194R	664194R	664194R	664194R	664194R
TOP PAN	496162R	496162R	496162R	496162R	496162R

Please specify the correct Model No., Serial No., and part number(s) when ordering parts from the nearest authorized dealer or service center.

