


REPLACEMENT PARTS LIST

H3HK HEATER KIT SINGLE & THREE PHASE SERIES



H3HK (5, 8, & 10 KW) SINGLE PHASE HEATER KITS

ITEM	DESCRIPTION	H3HK-005H-01C	H3HK-008H-01C	H3HK-010H-01C	H3HK-015H-01C	H3HK-015H-21C	H3HK-020H-01C	H3HK-020H-21C
1	COMPLETE HEATER KIT	917166C	917167C	917168C	917169C	917172C	917170C	917173C
2	SET OF WIRES	M0108001R	M0108002R	M0108002R	M0108003R	M0108003R	M0108004R	M0108004R
3	HEATING ASSEMBLY 1 ELEMENT	491214R	—	—	491214R	491214R	—	—
	HEATING ASSEMBLY - 2 ELEMENT	—	491226R	491225R	491225R	491225R	491225R	491225R
4	THERMAL LIMIT	626408	626407	626407	626409	626409	626409	626409
5	PACKAGE PARTS	730471R	730471R	730471R	730862R	730862R	730862R	730862R
6	CONTACTOR 2-POLES 25FLA	624830	624830	624830	624830	624830	624830	624830
7	BRACKET, SPACER ELEMENT (NOT SHOWN)	—	—	—	279031	279031	279031	279031
8	BRACKET, CONTACTOR	—	—	—	2C8061	2C8061	2C8061	2C8061
9	CIRCUIT BREAKER 2-POLE 60A	—	—	—	—	632215	—	632215
10	CLOSE-OFF PLATE MODIFIED	—	371096	371096	—	—	—	—

Please specify the correct Model No., Serial No., & part number(s) when ordering parts from the nearest authorized dealer or service center.

H3HK (9 & 15 KW) THREE PHASE HEATER KITS

ITEM	DESCRIPTION	H3HK-009Q-01C	H3HK-015Q-01C
1	COMPLETE HEATER KIT	903854C	903855C
2	SET OF WIRES	M0108005R	M0108005R
3	HEATING ASSEMBLY 1 ELEMENT	491216R	491214R
	HEATING ASSEMBLY - 2 ELEMENT	491227R	491225R
4	THERMAL LIMIT	626408	626410
5	PACKAGE PARTS	730813R	730813R
6	CONTACTOR 2-POLES 25FLA	624830	624830
7	BRACKET, SPACER ELEMENT (NOT SHOWN)	279031	279031
8	BRACKET, CONTACTOR	2C8061	2C8061
9	CIRCUIT BREAKER 2-POLE 60A	—	—
10	CLOSE-OFF PLATE MODIFIED	—	—

Please specify the correct Model No., Serial No., & part number(s) when ordering parts from the nearest authorized dealer or service center.

