

WIRING DIAGRAM

SMALL PACKAGED HEAT PUMP- SINGLE PHASE Q5RD/GQ5RD/PPH2RD 3 TON THRU 5 TON

208/230 VOLT

60HZ

NOTES:

1. Disconnect all power before servicing.
2. For supply connections use copper conductors only.
3. Not suitable on systems that exceed 150V to ground.

4. For replacement wires use conductors suitable for 105° C.

1. Couper le courant avant de faire le retretien.
2. Employez uniquement des conducteurs en cuivre.
3. Ne convient pas aux installations de plus de 150V a la terre.

