


REPLACEMENT PARTS LIST

MG2S DOWNFLOW
TWO STAGE CONDENSING GAS FURNACE
96+% AFUE



Front Return
with Coil Box



Top Return
with Coil Box

MG2S REPLACEMENT PARTS LIST

DESCRIPTION	045F	045T	060F	060T	072F	072T
BLOWER ASSEMBLY	1022912R	1022912R	1022912R	1022912R	1022912R	1022912R
BLOWER CONTROL BOARD	920920	920920	920920	920920	920920	920920
BLOWER DECK LIMIT SWITCH	626602R	626602R	626602R	626602R	626602R	626602R
BLOWER MOTOR	622684R	622684R	622684R	622684R	622684R	622684R
BLOWER MOTOR MOUNT KIT	904951	904951	904951	904951	904951	904951
BLOWER WHEEL	667258R	667258R	667258R	667258R	667258R	667258R
BURNER BOX ASSEMBLY	922017	922017	922018	922018	1022918R	1022918R
BURNER TUBE MANIFOLD	664639R	664639R	664639R	664639R	664640R	664640R
BURNER VIEW PORT (NOT SHOWN)	632216R	632216R	632216R	632216R	632216R	632216R
COIL DOOR ASSEMBLY (NOT SHOWN)	903094	903094	903094	903094	903094	903094
COMBUSTION AIR INLET PIPE	664645R	664645R	664645R	664645R	664645R	664645R
DOOR ASSEMBLY (LOUVERED) (BW MODELS)	922094	NA	922094	NA	922094	NA
DOOR ASSEMBLY (NON-LOUVERED) (BWT MODELS)	NA	922095	NA	922095	NA	922095
DOOR LATCH ASSEMBLY	1036349R	1036349R	1036349R	1036349R	1036349R	1036349R
DOOR SWITCH	632337R	632337R	632337R	632337R	632337R	632337R
DRAIN TEE	618060R	618060R	618060R	618060R	618060R	618060R
DRAIN TUBE (HARD "J") (NOT SHOWN)	663706R	663706R	663706R	663706R	663706R	663706R
DRAIN TUBE (SOFT, 23") (NOT SHOWN)	664434R	664434R	664434R	664434R	664434R	664434R
DRAIN TUBE (SOFT, 42") (NOT SHOWN)	664278R	664278R	664278R	664278R	664278R	664278R
FILTER (BWT MODELS)	NA	669779R	NA	669779R	NA	669779R
FLAME SENSOR	903600	903600	903600	903600	903600	903600
FURNACE CONTROL BOARD	624790R	624790R	624790R	624790R	624790R	624790R
FUSE	632261R	632261R	632261R	632261R	632261R	632261R
GAS VALVE	624787R	624787R	624787R	624787R	624787R	624787R
HEAT EXCHANGER (NOT SHOWN)	921597	921597	921597	921597	921598	921598
HIGH TEMP HOSE (NOT SHOWN)	263967R	263967R	263967R	263967R	263967R	263967R
IGNITER	1016290S	1016290S	1016290S	1016290S	1016290S	1016290S
INDUCER LIMIT SWITCH	626599R	626599R	626599R	626599R	626599R	626599R
INDUCER MOTOR WITH ORIFICE	1025335	1025335	1025335	1025335	1025335	1025335
INDUCER ORIFICE (NOT SHOWN)	670012R	1023976R	669749R	669718R	669719R	1021493R
INLINE DRAIN ASSEMBLY	664435R	664435R	664435R	664435R	664435R	664435R
INSHOT BURNER	661135R	661135R	661135R	661135R	661135R	661135R
MAIN AIR LIMIT SWITCH	626600R	626617R	626567R	626617R	626612R	626618R
ORIFICE (LP GAS)	661078R	661078R	661082R	661082R	661079R	661079R
ORIFICE (NATURAL GAS)	661049R	661049R	661045R	661045R	661047R	661047R
OUTLET HEADER BOX	904802	904802	904802	904802	904802	904802
PRESSURE SWITCH	1023972R	1023971R	1023972R	1023973R	1023972R	1023971R
ROLLOUT LIMIT SWITCH	626608R	626608R	626608R	626608R	626608R	626608R
SET OF WIRES (NOT SHOWN)	1021547R	1021547R	1021547R	1021547R	1021547R	1021547R
TRANSFORMER	622341R	622341R	622341R	622341R	622341R	622341R
VENT PIPE	664644R	664644R	664644R	664644R	664644R	664644R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

MG2S Gas Furnace Component Location

