


REPLACEMENT PARTS LIST

***G8SA ULTRA-LOW NOX SERIES,
SINGLE STAGE, NON-CONDENSING GAS FURNACE
80% AFUE**



80+ AFUE***G8SA UPFLOW / HORIZONTAL - REPLACEMENT PARTS LIST**

DESCRIPTION	*G8SA-055U-T23A1	*G8SA-070U-T24B1	*G8SA-100U-T35C1
Blower Housing	102401405R	N/A	N/A
Blower Housing & Wheel	N/A	1027025R	1027026R
Blower Limit	626611R	626611R	626611R
Blower Motor	1021614R	1021615R	1021617R
Blower Wheel	667256R	667374R	667280R
Collector Pan (w gasket)	1028587	1028588	1028589
Combustion Air Orifice	101874005R	101874001R	101874004R
Control Board	1025182R	1025182R	1025182R
Door Set	1028597FK	1028598FK	1028599FK
Door Switch	632693R	632693R	632693R
Flexible Gas Line (Stainless Steel)	1025318R	1025318R	1025318R
Fuse	632261R	632261R	632261R
Gas/Air Venturi	1018739R	1018739R	1018739R
Gas/Air Venturi Gasket Only (Qty: 2)	1028586	1028586	1028586
Gas Orifice (Natural Gas)	1025320R	661026R	661016R
Gas Valve	624775R	624775R	624775R
Heat Exchanger	102160701R	102160702R	102160704R
High Temp Hose (Not Shown)	263967R	263967R	263967R
Ignitor & Flame Sensor Assembly (Includes bracket and gasket)	1021611R	1021611R	1021611R
Ignitor/Flame Sensor Gasket Only (Not Shown, Qty: 20)	1028600	1028600	1028600
Inducer Gasket (Not Shown)	689988R	689988R	689988R
Inducer Motor (w/Gasket)	1028582	1028583	1028584
Main Air Limit Switch	1018470R	1018470R	626616R
Motor Mount Kit	904951	904951	904951
Pre-Mix Burner Head Assembly	1028590	1028591	1028592
Pressure Switch	1018505R	1018505R	1018505R
Roll-Out Limit Switch	1027311R	1027064R	1027062R
Set of Wires (Not Shown)	1025311R	1025311R	1021579R
Top Panel	295911R	295912R	295913R
Transformer	622341R	622341R	622341R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

