


REPLACEMENT PARTS LIST

***SD ULTRA-LOW NOX SERIES,
SINGLE STAGE, CONDENSING GAS FURNACE
95% AFUE**



95% AFUE***SD 050U-23EA ULTRA-LOW NOX SERIES -
REPLACEMENT PARTS LIST**

DESCRIPTION	*G8SD 050U-23EA
	1032279F
Air / Fuel Mixing Tube	1032274R
Air intake Gasket	1025345R
Barbed Elbow Connector	664889R
Blower Assembly	1027024R
Blower Bracket	101878101R
Blower Door (Bottom Door)	295091R
Blower Limit Switch (Not Shown)	626611R
Blower Motor	1029940R
Burner Door (Top Door)	294751R
Collector Pan (With Gasket)	1035004
Collector Pan Gasket	1018708R
Combustion Air Orifice (1.050")	1035005
Combustion Box Gasket	1018765R
Control Board	1029952R
Control Board Panel	103213801R
Corner Wrapper Insert (Right - Not Shown)	618074R
Corner Wrapper Insert (Left - Not Shown)	618073R
Door Switch	632693R
Drain Tube (Hard "J") (Not Shown)	663706R
Drain Tube (Soft "J" 30") (Not Shown)	663707R
Drain Tube (Soft "J") (Not Shown)	664886R
Drain Tube (Soft 6.25") (Not Shown)	664878R
Drain Tube (Soft 9.0") (Not Shown)	1034969R
Flexible Gas Line (Stainless Steel)	1025318R
Fuse (5-Amp - Not Shown)	632269R
Gas/Air Venturi Gasket Only	1025345R
Gas Orifice (#30 Drill)	661030R
Gas Orifice Housing (Natural Gas)	1018790R
Gas Valve	624775R
Gas Valve Bracket	1035784
Heat Exchanger Assembly	103009840R
Ignitor / Flame Sensor Assembly	1021611R
Ignitor / Flame Sensor Bracket	101878201R
Ignitor / Flame Sensor Gasket	1018784R
Inducer Gasket (Not Shown)	690283R
Inducer Limit Switch (Not Shown)	626599R
Inducer Motor (With Gasket)	1035783
Main Air Limit	626481R
Manifold	1018750R
Motor Choke	622340R
Motor Mount Kit	M0026808R
Pipe Nipple (1/2" x 1/2")	1018787R
Pipe Plug (1/2")	1035002R
Pre-Mix Burner Gasket	1018765R
Pre-Mix Burner Head Assembly	1035785
Pressure Switch - Double	1016295R
Pressure Switch - Single	1013436R
PVC Tee (2"x2"x2")	663115R
PVC Trap	664969R
Set of Wires	103009818R
Site Glass Assembly	103009803R
Spring Clamp (7/8")	606315R
Spring Clamp Hose	606286R
Top Panel	2B3551R
Transducer	1029942R
Transformer	622341R
Union (5/8"O.D., Tube, 45° Flare x 1/2" NPTF)	1032984R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

95% AFUE***SD 100U-35EC ULTRA-LOW NOX SERIES -
REPLACEMENT PARTS LIST**

DESCRIPTION	*G8SD 100U-35EC
	1032284F
Air / Fuel Mixing Tube	1032274R
Air intake Gasket	1025345R
Barbed Elbow Connector	664889R
Blower Assembly	1029938R
Blower Bracket	101878103R
Blower Door (Bottom Door)	295093R
Blower Limit Switch (Not Shown)	626611R
Blower Motor	1029941R
Burner Door (Top Door)	294753R
Collector Pan (With Gasket)	1035007
Collector Pan Gasket	1018710R
Combustion Air Orifice (1.380")	1035006
Combustion Box Gasket	1018764R
Control Board	1029953R
Control Board Panel	103213901R
Corner Wrapper Insert (Right - Not Shown)	618074R
Corner Wrapper Insert (Left - Not Shown)	618073R
Door Switch	632693R
Drain Tube (Hard "J") (Not Shown)	663706R
Drain Tube (Soft "J" 30") (Not Shown)	663707R
Drain Tube (Soft "J") (Not Shown)	664886R
Drain Tube (Soft 6.25") (Not Shown)	664878R
Drain Tube (Soft 9.0") (Not Shown)	1034969R
Flexible Gas Line (Stainless Steel)	1025318R
Fuse (5-Amp - Not Shown)	632269R
Gas/Air Venturi Gasket Only	1025345R
Gas Orifice (#16 Drill)	661016R
Gas Orifice Housing (Natural Gas)	1018790R
Gas Valve	624775R
Gas Valve Bracket	1035784
Heat Exchanger Assembly	103009804R
Ignitor / Flame Sensor Assembly	1021611R
Ignitor / Flame Sensor Gasket	1018784R
Ignitor / Flame Sensor Bracket	101878201R
Inducer Gasket (Not Shown)	690283R
Inducer Limit Switch (Not Shown)	626599R
Inducer Motor (With Gasket)	1035783
Main Air Limit	626600R
Manifold	1018750R
Motor Choke	622340R
Motor Mount Kit	M0026808R
Pipe Nipple (1/2" x 1/2")	1018787R
Pipe Plug (1/2")	1018786R
Pre-Mix Burner Gasket	1018764R
Pre-Mix Burner Head Assembly	1035786
Pressure Switch - Double	1016295R
Pressure Switch - Single	1013436R
PVC Tee (2"x2"x2")	663115R
PVC Trap	664969R
Set of Wires	103009819R
Site Glass Assembly	103009803R
Spring Clamp (7/8")	606315R
Spring Clamp Hose	606286R
Top Panel	2B3553R
Transducer	1029942R
Transformer	622341R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

