


REPLACEMENT PARTS LIST

**VG8SA ULTRA-LOW NOX SERIES,
SINGLE STAGE, NON-CONDENSING GAS FURNACE**

80% AFUE



80+ AFUE**VG8SA UPFLOW / HORIZONTAL - REPLACEMENT PARTS LIST**

DESCRIPTION	VG8SA-055U-T23AP	VG8SA-070U-T24BP	VG8SA-100U-T35CP
Blocked Vent Limit Switch	1039638R	1039637R	1039636R
Blower Housing	102401405R	N/A	N/A
Blower Housing & Wheel	N/A	1027025R	1027026R
Blower Limit	626611R	626611R	626611R
Blower Motor	104877101R	104877102R	104877103R
Blower Wheel	667256R	667374R	667280R
Burner Head Gasket	1018765R	1018766R	1018764R
Collector Pan (with Gasket)	1028587	1028588	1028589
Combustion Air Orifice	101874006R	101874001R	101874004R
Control Board	1039191R	1039191R	1039191R
Door Set	1039562V	1039563V	1039564V
Door Switch	632693R	632693R	632693R
Flexible Gas Line (Stainless Steel)	1025318R	1025318R	1025318R
Fuse	632261R	632261R	632261R
Gas/Air Venturi	1018739R	1018739R	1018739R
Gas/Air Venturi Gasket Only (Qty: 2)	1028586	1028586	1028586
Gas Orifice (Natural Gas)	1025320R	661026R	661016R
Gas Valve	624775R	624775R	624775R
Heat Exchanger	102160701R	102160702R	102160704R
High Temp Hose (Not Shown)	263967R	263967R	263967R
Ignitor & Flame Sensor Assembly (Includes bracket and gasket)	1021611R	1021611R	1021611R
Ignitor/Flame Sensor Gasket Only (Not Shown, Qty: 20)	1028600	1028600	1028600
Inducer Gasket Only (Not Shown)	689988R	689988R	689988R
Inducer Motor (with Gasket)	1039559	1039560	1039561
Main Air Limit Switch	1018470R	1018470R	626616R
Motor Mount Kit	904951	904951	904907
Pre-Mix Burner Head Assembly	1028590	1028591	1028592
Pressure Switch	1010416R	1010416R	1010416R
Set of Wires (Not Shown)	1025311R	1025311R	1021579R
Top Panel	295911R	295912R	295913R
Transformer	622341R	622341R	622341R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

