

REPLACEMENT PARTS LIST

**SINGLE PACKAGE GAS HEATING / ELECTRIC COOLING
J4PG SERIES, ULTRA LOW NOX, 13.4 SEER2, SINGLE PHASE MODELS**



IMPORTANT

- This document is primarily intended to assist qualified individuals experienced in the proper repair or servicing of this appliance. Only factory authorized parts or accessory kits may be used with this product. Improper installation, service, adjustment, or maintenance may cause explosion, fire, electrical shock or other hazardous conditions which may result in personal injury or property damage.
- Some local codes require licensed installation / service personnel to service this type of equipment. Under no circumstances should the equipment owner attempt to install parts or service this equipment. Failure to comply with this warning could result in property damage, personal injury, or death.

J4PG Ultra Low NOx Single Package Gas Heating / Electric Cooling Units 13.4 SEER2, Single Phase Models


DESCRIPTION	J4PG 4L24B1055A	J4PG 4L30B1070A	J4PG 4L36B1070A	J4PG 4L42B1100A	J4PG 4L48B1100A	J4PG 4L60B1100A
	1040868X	1040869X	1040870X	1040871X	1040872X	1040873X
ACCESS FITTING	663812R	663812R	663812R	663812R	663812R	663812R
AUTOTRANSFORMER (200VA, 230 TO 115V)	1036083R	1036083R	1036083R	1036083R	1036083R	1036083R
BLOWER HOUSING	D07484R	D07484R	D07484R	D07484R	D07484R	D07484R
BLOWER MOTOR	104218909R	104218910R	104218911R	104218912R	104218913R	104218914R
BLOWER MOTOR MOUNT KIT	903489	903489	903489	903489	903489	903489
BLOWER SERVICE PANEL ASSY	D05548HR	D05548HR	D05548HR	103929238R	D05543HR	103929249R
BLOWER WHEEL (11 X 10)	667277R	667277R	667277R	667277R	667277R	667277R
CAPACITOR	01-0084	01-0269	01-0271	01-0269	01-0278	01-0279
COIL GUARD (FORMED)	2A8452R	2A8452R	2A8452R	2A8453R	2A8454R	2C5161R
COLLECTOR PAN (W/O RETAINER)	1040152	1040152	1040152	1040153	1040153	1040153
COLLECTOR PAN GASKET	689506R	689506R	689506R	103610501R	103610501R	103610501R
COMBUSTION AIR ORIFICE PLATE	1043390	1043388	1043388	1043389	1043389	1043389
COMPRESSOR	921423	921425	921427	1033661R	921466	921468
CONTACTOR	1014863R	1014863R	1014864R	1014865R	1014865R	1014865R
CONTROL BOARD	1039191R	1039191R	1039191R	1039191R	1039191R	1039191R
CORNER PANEL	103929206R	103929206R	103929206R	103929241R	104087803HR	103929252R
CORNER POST	D09994HR	D09994HR	D09994HR	D09996HR	D09997HR	2B1941HR
DISTRIBUTOR ASSY	664518R	664595R	664689R	664599R	664691R	—
DRAIN PAN ASSEMBLY (INCLUDES DRAIN TUBE)	D05700R	D05700R	D05700R	D05700R	D05700R	D05700R
EXHAUST DUCT	102523701R	102523701R	102523701R	102523701R	102523701R	102523701R
EXTERNAL SERVICE BRACKET	298552HR	298552HR	298552HR	298552HR	298552HR	298552HR
FAN BLADE	667356R	667278R	667278R	667356R	1024013R	667319R
FAN GRILLE (BLACK)	669404R	669404R	669404R	669404R	1034994R	1034994R
FAN ORIFICE	263210HR	263210HR	263210HR	263210HR	295481HR	295481HR
FILTER DRIER (8 IN ³)	669764R	669764R	669764R	669764R	669764R	669764R
FILTER	1039259R	1039259R	1039259R	1039259R	1039259R	1039259R
FLEXIBLE GAS CONNECTOR (5/8" D X 16" L)	1039233R	1039233R	1039233R	1039233R	1039233R	1039233R
FRONT PANEL	298891HR	298891HR	298891HR	298892HR	298893HR	298895HR

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

J4PG Ultra Low NOx Single Package Gas Heating / Electric Cooling Units 13.4 SEER2, Single Phase Models continued

DESCRIPTION	J4PG 4L24B1055A	J4PG 4L30B1070A	J4PG 4L36B1070A	J4PG 4L42B1100A	J4PG 4L48B1100A	J4PG 4L60B1100A
	1040868X	1040869X	1040870X	1040871X	1040872X	1040873X
FUSE HOLDER (NOT SHOWN)	RZ060241	RZ060241	RZ060241	RZ060241	RZ060241	RZ060241
FUSE TIME-DELAY (AUTOTRANSFORMER)	RZ261956	RZ261956	RZ261956	RZ261956	RZ261956	RZ261956
GAS/AIR VENTURI	1018739R	1018739R	1018739R	1018739R	1018739R	1018739R
GAS VALVE	624775R	624775R	624775R	624775R	624775R	624775R
HAIL GUARD KIT (NOT SHOWN)	917206	917206	917206	917206	917206	917206
HEAT EXCHANGER	103612031R	103612031R	103612031R	103612008R	103612008R	103612008R
HIGH PRESSURE SWITCH AUTO RESET (NOT SHOWN)	632473R	632473R	632473R	632473R	632473R	632473R
HORIZONTAL DUCT COVER	283101HR	283101HR	283101HR	283101HR	283101HR	283101HR
IGNITOR / FLAME SENSOR ASSEMBLY	1021611R	1021611R	1021611R	1021611R	1021611R	1021611R
INDOOR COIL (EVAP COIL)	1017857R	1017857R	1017857R	1017853R	1017858R	1017854R
INDUCER GASKET	689988R	689988R	689988R	689988R	689988R	689988R
INDUCER MOTOR	1040149	1040150	1040150	1040151	1040151	1040151
LOUVERED SERVICE PANEL	103929207R	103929207R	103929207R	103929242R	104087903HR	103929251R
MAIN AIR LIMIT SWITCH (185/165)	626445R	626445R	626445R	626445R	626445R	626445R
MAIN BURNER ORIFICE (NOT SHOWN)	661030R	661026R	661026R	661016R	661016R	661016R
MOLDED PLUG HV / COMPRESSOR PLUG (NOT SHOWN)	634715R	634715R	634715R	634715R	634715R	634830R
OUTDOOR COIL (CONDENSER COIL)	1010327R	1010327R	1010327R	1010325R	1010326R	1010328R
OUTDOOR FAN MOTOR	622080	622757R	622757R	922022	622757r	622757r
PRESSURE SWITCH (0.20)	1018505R	1018505R	1018505R	1018505R	1018505R	1018505R
RELAY	622180R	622180R	622180R	622180R	622180R	622180R
RESTRICTOR (PISTON)	664057R	664062R	664068R	664074R	664076R	—
RETURN AIR PANEL	D05567HR	D05567HR	D05567HR	103929240R	D05566HR	103929250R
SET OF WIRES (NOT SHOWN)	104218902R	104218902R	104218902R	104218924R	104218902R	104218923R
SUPPLY AIR PANEL	D05558HR	D05558HR	D05558HR	103929239R	D05557HR	D05569HR
TEMPERATURE LIMIT SWITCH	1039638R	1039638R	1039638R	1039638R	1039638R	1039638R
TERMINAL BLOCK	632695R	632695R	632695R	632695R	632695R	632695R
TXV	—	—	—	—	—	664275R
TOP PAN ASSEMBLY	292441HR	292441HR	292441HR	292441HR	103929256R	103929256R
TOUCH-UP PAINT ANTHRACITE GRAY (NOT SHOWN)	1032136R	1032136R	1032136R	1032136R	1032136R	1032136R
TRANSFORMER (40 VA)	621709R	621709R	621709R	621709R	621709R	621709R
VENT COVER	265040R	265040R	265040R	265040R	265040R	265040R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.



Trane Technologies
6200 Troup Hwy
Tyler, Texas 75707

For more information, contact your local dealer (distributor).



D3141120
(NEW)