


REPLACEMENT PARTS LIST

U-CROWN SYSTEM

OUTDOOR UNIT

GXH18(5.2)KSK4DH

ITEM #	COMPONENT
1	FRONT GRILL
2	FRONT PANEL ASSY
3	FRONT SIDE PLATE SUB-ASSY
4	CHASSIS SUB-ASSY
5	ELECTRICAL HEATER (CHASSIS)
6	COMPRESSOR AND FITTINGS
7	4-WAY VALVE ASSY
8	ELECTRONIC EXPANSION VALVE ASSY
9	RIGHT SIDE PLATE
10	VALVE SUPPORT SUB-ASSY
11	VALVE COVER
12	CUT OFF VALVE
13	CUT OFF VALVE SUB-ASSY
14	BIG HANDLE
15	MAGNET COIL
16	TEMPERATURE SENSOR
17	CONDENSER ASSY
18	REACTOR
19	TOP COVER SUB-ASSY
20	CONDENSER SUPPORT PLATE
21	MOTOR SUPPORT ASSY
22	LEFT SIDE PLATE
23	LEFT HANDLE
24	BRUSHLESS DC MOTOR
25	CLAPBOARD SUB-ASSY
26	AXIAL FLOW FAN
27	ELECTRIC BOX ASSY
28	TERMINAL BOARD
29	TERMINAL BOARD SUPPORT SUB-ASSY
30	RADIATOR
31	MAIN BOARD
32	ELECTRIC BOX COVER



GXH18(5.2)KSK4DH

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
1	Front Grill	016004060005	1003126
2	Front Panel Assy	0153501405	1025080
3	Front Side Plate Sub-Assy	01303249P	1032472
4	Chassis Sub-Assy	02803315P	1041675
5	Electrical Heater (Chassis)	7651000411	1032521
6	Compressor and Fittings	00105251	1025124
7	4-Way Valve Assy (Reversing Valve Assy)	030152000081	1041677
8	Electronic Expansion Valve Assy (EEV Assy)	03017400017	1041678
9	Right Side Plate	0130504402P	1032354
10	Valve Support Sub-Assy	0170506101P	1041679
11	Valve Cover	22245003	1041680
12	Cut off Valve 5/8	0713517901	1041681
13	Cut off Valve Sub-Assy 1/4	07133934	1041682
14	Big Handle	02115005	1028753
15	Magnet Coil (Reversing Valve Coil)	4300040045	1014099
16	Temperature Sensor 20KT/15KS/50KT-XARP-06V-1200/800/600mm	3900030901	1008287
17	Condenser Coil Assy	01100200326	1041683
18	Reactor	43130024	1031684
19	Top Cover Sub-Assy	000051000026	1045134
20	Condenser Support Plate	01175092	1028784
21	Motor Support Assy	017012000017	1045133
22	Left Side Plate	01305043P	1032363
23	Left Handle	—	—
24	Brushless DC Motor	15010400000102	1025125
25	Clapboard Sub-Assy	01235091	1041688
26	Axial Flow Fan (Blade)	10335013	1025126
27	Electric Box Assy	10000100222	1041689
28	Terminal Block	42200006001401	1045132
29	Terminal Board Support Sub-Assy	01715016	1041690
30	Radiator	49015215	1032362
31	Main Board	30138000652	1041692

GXH18(5.2)KSK4DH

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
32	Electric Box Cover	20125002	1041693
33	Silencer (Not Shown)	07245007	1044619
34	Silencer (Not Shown)	07245012	1032677
35	Strainer (Not Shown)	07216221	1032616
36	Strainer (Not Shown)	0721304401	1032675
37	Inductance (Not Shown)	43120006	1025129
38	Relay (Not Shown)	44020399	1045131
39	Relay (JZC-32F-012-H) (Not Shown)	44020345	1045130
40	Fuse (T3.15AH250V) (Not Shown)	46010030	1045129
41	Rectifier (25A/800V) (Not Shown)	46010609	1045107
42	Rectifier (800V 1.5A) (Not Shown)	46010614	1045128
43	Magnet Coil (Not Shown)	4304000415	1045127
44	Magnetic Ring (Not Shown)	49010109	1025139
45	Rear Grill (Not Shown)	01475013	1032365
46	Drainage Hole Cap (Not Shown)	7671301802	1032782
47	Drainage Joint (Not Shown)	06123401	1008701
48	Compressor Overload Protector (External) (HPC 115/95) (Not Shown)	00183051	1032779
49	Compressor Overload Protector (External) (KSD115°) (Not Shown)	00183032	1032780
50	Temperature Sensor (20KT-JST-XARP-03V-650mm) (Not Shown)	39000072	1045126

