


REPLACEMENT PARTS LIST

17 SEER2 SINGLE ZONE, LSK4DL2

HEAT PUMP OUTDOOR UNIT

GXH12(3.5)LSK4DL2

ITEM #	COMPONENT
1	TOP COVER ASSY
2	SUPPORTING BOARD (CONDENSER)
3	4-WAY VALVE (REVERSING VALVE)
4	SPONGE (CONDENSER)
5	TEMPERATURE SENSOR SUPPORT
6	CONDENSER ASSY (COIL)
7	TEMP SENSOR SLEEVING
8	SENSOR INSERT
9	RIGHT SIDE PLATE
10	EARTHING PLATE SUB-ASSY
11	WIRE CLAMP
12	ELECTRONIC EXPANSION VALVE
13	ELECTRIC EXPAND VALVE FITTING
14	VALVE COVER
15	SILENCER
16	CUT OFF VALVE SUB-ASSY
17	STRAINER
18	CUT OFF VALVE ASSY
19	VALVE SUPPORT
20	4-WAY VALVE ASSY (REVERSING VALVE ASSY)
21	COMPRESSOR AND FITTINGS
22	CHASSIS SUB-ASSY
23	MOTOR SUPPORT
24	BRUSHLESS DC MOTOR (FAN MOTOR)
25	AXIAL FLOW FAN (FAN BLADE)
26	FRONT PANEL ASSY
27	FRONT GRIL
28	DRAINAGE JOINT (ODU)
29	LEFT SIDE PLATE
30	CLAPBOARD
31	REACTOR
32	ELECTRIC BOX ASSY
33	ELECTRIC BOX
34	MAIN BOARD
35	ELECTRIC BOX COVER
36	TERMINAL BOARD
37	TEMPERATURE SENSOR
38	RADIATOR



GXH12(3.5)LSK4DL2

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
1	Top Cover Assy	000097060345	1045597
2	Supporting Board (Condenser)	NONE	—
3	4-Way Valve (Reversing Valve)	072007060013	1045715
4	Sponge (Condenser)	1212309101	1045721
5	Temperature Sensor Support	NONE	—
6	Condenser Assy (Coil)	011002061547	1045432
7	Temp Sensor Sleeveing	05212423	1032335
8	Sensor Insert	42020063	1045651
9	Right Side Plate	01205606038406P01	1045601
10	Earthing Plate Sub-Assy	NONE	—
11	Wire Clamp	200015060025	1045719
12	Electronic Expansion Valve	NONE	—
13	Electric Expand Valve Fitting	NONE	—
14	Valve Cover	200087060004	1045603
15	Silencer	035023000009	1045602
16	Cut Off Valve Sub-Assy	030057060359	1045718
17	Strainer	07210022	1032546
18	Cut Off Valve Assy	NONE	—
19	Valve Support	012044060022P	1045606
20	4-Way Valve Assy (Reversing Valve Assy)	030152060905	1045425
21	Compressor and Fittings	009001060648	1045428
22	Chassis Sub-Assy	017000060724P	1045607
23	Motor Support	012048060149	1045609
24	Brushless DC Motor (Fan Motor)	150104060095	1045474
25	Axial Flow Fan (Fan Blade)	10333428	1045610
26	Front Panel Assy	00000306073401	1045611
27	Front Grill	016004060016	1045612
28	Drainage Joint (ODU)	26113009	1032573
29	Left Side Plate	012055060397P01	1045591
30	Clapboard	012051060895	1045608
31	Reactor	NONE	—
32	Electric Box Assy	100002075882	1045714
33	Electric Box	200013060073	1045594
34	Main Board	300027062375	1045418
35	Electric Box Cover	20008206005801	1045593
36	Terminal Board	42200006007501	1045572
37	Temperature Sensor	3900030811	1045430
38	Radiator	430034060108	1045716
39	Cut-off valve 3/8(N) (Not Shown)	070001060029	1045605
40	Cut-off valve 1/4(N) (Not Shown)	070001060022	1045604
41	Capillary Sub-Assy (Not Shown)	030006061780	1045419
42	Magnet Coil (Reversing Valve Coil)(Not Shown)	4300040072	1014115
43	Rear Grill (Not Shown)	016001060095	1045598
44	Electrical Heater (Chassis)(Not Shown)	7651000423	1045581
45	Strainer (Fork Shape)(Not Shown)	072111031	1041695

