


REPLACEMENT PARTS LIST

25 SEER2 SINGLE ZONE, LSK4DH2

HEAT PUMP OUTDOOR UNIT

GXH12(3.5)LSK4DH2

ITEM #	COMPONENT
1	FRONT GRILL
2	CABINET
3	AXIAL FLOW FAN
4	BRUSHLESS DC MOTOR
5	CHASSIS SUB ASSY
6	CLAPBOARD ASSY
7	COMPRESSOR AND FITTINGS
8	VALVE SUPPORT BLOCK
9	VALVE COVER
10	VALVE SUPPORT
11	CUT-OFF VALVE 1/2(N)
12	CUT-OFF VALVE 1/4(N)
13	HANDLE (RIGHT)
14	RIGHT SIDE PLATE ASSY
15	SUCTION TUBE ASSY
16	CONDENSER ASSY
17	REAR GRILL
18	TOP COVER ASSY
19	MOTOR SUPPORT SUB ASSY
20	LEFT SIDE PLATE
21	ELECTRIC BOX COVER
22	MAIN BOARD
23	ELECTRIC BOX ASSY
24	TERMINAL BOARD



GXH12(3.5)LSK4DH2

	PART DESCRIPTION	PART CODE	NORTEK PART NUMBER
1	Front Grill	016004060011	1045586
2	Cabinet	01202206001002P01	1045585
3	Axial Flow Fan	103002060015	1045584
4	Brushless DC Motor	15010406009503	1045400
5	Chassis Sub Assy	017000060759P	1045712
6	Clapboard Assy	000075060126	1045711
7	Compressor and Fittings	009001060664	1045398
8	Valve Support Block	NONE	—
9	Valve Cover	200087060004	1045603
10	Valve Support	012044060022P	1045606
11	Cut-off Valve 1/2(N)	070001060024	1045710
12	Cut-off valve 1/4(N)	070001060022	1045604
13	Handle(Right)	NONE	—
14	Right Side Plate Assy	00008106028901	1045883
15	Suction Tube Assy	NONE	—
16	Condenser Assy	011002062026	1045397
17	Rear Grill	016001060082	1045575
18	Top Cover Assy	000097060355	1045574
19	Motor Support Sub Assy	NONE	—
20	Left Side Plate	012055060395P01	1045567
21	Electric Box Cover	NONE	—
22	Main Board	300027062544	1045395
23	Electric Box Assy	100002076321	1045881
24	Terminal Board	42200006007501	1045572
25	Electrical Heater (Chassis) (Not Shown)	7651000423	1045581
26	4-Way Valve Assy (Not Shown)	030152061146	1045396
27	Magnet Coil (Not Shown)	4300040072	1014115
28	Electronic Expansion Valve (Not Shown)	072009000017	1045402
29	Electric Expand Valve Fitting (Not Shown)	07200206002213	1045401
30	Temperature Sensor (Not Shown)	3900030905	1045470
31	Drainage Joint (Not Shown)	26113009	1032573
32	Drainage Hole Cap (Not Shown)	06813401	1032515

