



REPLACEMENT PARTS LIST

MG1E-B SERIES

DIRECT VENT, FORCED AIR, GAS FURNACES





MG1E-B SERIES FURNACES

	DESCRIPTION	MG1E-B			
		MG1E-B056AF1(A,B)M1	MG1E-B070F1A(A,B)M1	MG1E-B077F1A(A,B)M1	MG1E-B090F1A(A,B)M1
1	Air Filter	669064R	669064R	669064R	669064R
2	Air Orifice Flange	263871R	263872R	263873R	263875R
3	Air Pipe	387210R	387210R	387210R	387210R
4	Air Temperature Limit Switch	626470R	626618R	626618R	626618R
5	Auxiliary Limit Switch	626619R	626619R	626619R	626619R
6	Blower Housing	297217R	297217R	297217R	297217R
7	Blower Motor	104856001R	104856002R	104856003R	104856004R
8	Blower Wheel	667258R	667258R	667258R	667258R
9	Burner (less Orifice)	903406	903406	903406	903406
10	Burner Spud (Not Shown)	663699R	663699R	663699R	663699R
11	Coil Close-Off Plate (Left) (Not Shown)	104848301R	104848301R	104848301R	104848301R
12	Coil Close-Off Plate (Right) (Not Shown)	104848401R	104848401R	104848401R	104848401R
13	Coil Door (White) (Not Shown) *See Note below	104852601R	104852601R	104852601R	104852601R
14	Combustion Air Baffle Kit (Not Shown)	903722	903722	903722	903722
15	Combustion Blower Assembly	903404	903404	903404	903404
16	Door Latch (Furnace Door)	1036349R	1036349R	1036349R	1036349R
17	Door Latch (Coil Door) (Not Shown)	668420R	668420R	668420R	668420R
18	Door Strike (Coil Door) (Not Shown)	1018719	1018719	1018719	1018719
19	Elbow Assembly (Not Shown)	1045069R	1045069R	1045069R	1045069R
20	Filter Retainer Wire	669065R	669065R	669065R	669065R
21	Flame Sensor (Not Shown)	632484R	632484R	632484R	632484R
22	Gas Entry Plate	383610	383610	383610	383610
23	Gas Valve	1046626	1046626	1046626	1046626
24	Gasket Kit (Not Shown)	730534R	730534R	730534R	730534R
25	Heater Exchange	903418	903419	903419	903420
26	Ignitor	903110A	903110A	903110A	903110A
27	Integrated Control	1041648R	1041648R	1041648R	1041648R
28	Louvered Door (White)	903407	903407	903407	903407
29	Motor Mount Kit	903489	903489	903489	903489
30	Orifice, LP Gas (Not Shown)	661045R	661042R	661040R	661036R
31	Orifice, Natural Gas (Not Shown)	661029R	661024R	661021R	661017R
32	Observation Door Assembly	264080R	264080R	264080R	264080R
33	On/Off Switch	632337R	632337R	632337R	632337R
34	Pressure Switch	1010775R	1010775R	1010775R	1010775R
35	Set of Wires (Not Shown)	1035924R	1035924R	1035924R	1035924R
36	Transformer	621807R	621807R	621807R	621807R
37	Venturi Assy	660886R	660886R	660886R	660886R

* For factory installed 20" coil box

