

REPLACEMENT PARTS LIST

M5S SERIES OIL FURNACE
83% AFUE




M5SB REPLACEMENT PARTS LIST (SEE PAGE 3 FOR COMPONENT LOCATIONS)

NEW M5 RPL PICTURE	DESCRIPTION	M5SB OIL FURNACE	
		M5SB-B066A-(A,B)W1	M5SB-B086A-(A,B)W1
1	Louvered Door (White)	903407	903407
2	Door Latch (Furnace Door)	1036349R	1036349R
3	Door Latch (Coil Door)	668420R	668420R
4	Door Strike (Coil Door)	1018719	1018719
5	Air Filter	669064R	669064R
6	Filter Retainer Wire	669065R	669065R
7	Blower Housing	D07482R	D07482R
8	Blower Motor	903774	903774
9	Blower Wheel	667037R	667037R
11	Auxiliary Limit Switch	626619R	626619R
12	Capacitor	01-0024	01-0025
13	Air Pipe	386542R	386542R
15	Fuse (Not shown)	632261R	632261R
16	On/Off Switch	632337R	632337R
17	Transformer	621807R	621807R
18	Fan Control Switch	626468R	626468R
19	Blower Relay	621867R	621867R
20	Heat Exchanger	903422	921144
21	Reducer Coupling	669063R	669063R
22	Flexible Hose	663734R	663734R
23	Burner	903945	903946
24	Burner Plate	383690R	383690R
25	Chamber Ring	383600R	383600R
26	Combustion Chamber	903423	903423
27	Coil Door	104852601R	104852601R
28	Coil Close-Off Plate (left)	104848301R	104848301R
29	Coil Close-Off Plate (Right)	104848401R	104848401R
30	Gasket Door (Not Shown)	730534R	730534R
31	Air Temp Limit	626618R	626618R
32	Observation Door Assembly (Not Shown)	264080R	264080R
33	Receptacle (Not Shown)	632482R	632482R

Please specify the correct Model No., Serial No, and part number(s) when ordering parts from the nearest authorized dealer or service center.

M5S Oil Furnace Component Location

CONVERSION KITS	MODEL	PART NO.
OIL TO GAS BURNER CONVERSION	066	903426
OIL TO GAS BURNER CONVERSION	086	903427



M5S(*) OIL BURNER

ITEM	DESCRIPTION	PART NUMBER	ITEM	DESCRIPTION	PART NUMBER
1	Motor	621945	12	Gasket Kit (Inlet Box)	660915
2	Primary Control (Genisys)	1003164	13	Air Tube Assembly	660918
3	Transformer	621943R	14	Burner Head	660468
4	Gasket Kit (Transformer)	660914	15	Nozzle Adapter	660059R
5	Burner Housing Assembly	660282	16	Electrode Kit	660917
6	Eschutcheon Plate	660592	17	Blower Wheel	103995000R
7	Locknut	660593	18	Power Supply cord	634568
8	Oil Line Kit	660594	19	Nozzle, 066	660606
9	Fuel Pump	622090	19	Nozzle, 086	660605R
10	Solenoid Valve Kit	624648	20	Flame Decetor	660603
11	inlet Air Box Assembly	660928	23	Gun Drawer Assembly	660916R

Please specify the correct Model No., Serial No., and part number(s) when ordering parts from the nearest authorized dealer or service center.

