

REPLACEMENT PARTS LIST


FLEX MATCH SYSTEM

CASSETTE TYPE INDOOR UNIT

SKU: 1009443

GKH24(7.0)FMK4DH

ITEM #	COMPONENT
1	TUBE EXIT PLATE ASSY
2	SHELL ASSY
3	BODY INSTALLING PLATE
4	FRONT SIDE PLATE ASSY
5	LEFT SIDE PLATE ASSY
6	BASE PLATE ASSY
7	REAR SIDE PLATE ASSY
8	BOTTOM FOAM ASSY
9	MOTOR GASKET
10	MOTOR SUPPORT
11	FAN MOTOR
12	CENTRIFUGAL FAN
13	CONNECTED BOARD ASSY OF EVAPORATOR
14	FILTER SUB-ASSY
15	DRAIN HOSE SUB-ASSY
16	WATER TRAY ASSY
17	ELECTRIC BASE PLATE
18	DIVERSION CIRCLE
19	ELECTRIC BOX ASSY
20	TRANSFORMER
21	TERMINAL BOARD
22	ELECTRIC BOX COVER
23	ELECTRIC BOX COVER SUB-ASSY1
24	TEMPERATURE SENSOR
25	AMBIENT TEMPERATURE SENSOR
26	ELECTRIC BOX COVER SUB-ASSY2
27	ELECTRIC BOX COVER
28	MAIN BOARD
29	CAPACITOR CBB61
30	EVAPORATOR ASSY
31	EVAPORATOR SUPPORT ASSY
32	MAGNETIC RING
33	WATER PUMP
34	WATER PUMP ASSY
35	PUMP SUPPORT
36	WATER LEVEL SWITCH
37	PUMP DRAINPIPE
38	RIGHT SIDE PLATE ASSY
39	REMOTE CONTROLLER
40	PUMP COVER BOARD ASSY
41	DISPLAY BOARD



GKH24(7.0)FMK4DH

PART DESCRIPTION	PART CODE	NORTEK PART NUMBER	LIST PRICE
TUBE EXIT PLATE ASSY	0138271502		
SHELL ASSY	01432704		
BODY INSTALLING PLATE	01332701		
FRONT SIDE PLATE ASSY	01302718		
LEFT SIDE PLATE ASSY	01302715		
BASE PLATE ASSY	01222701		
REAR SIDE PLATE ASSY	01302714		
BOTTOM FOAM ASSY	52012722		
MOTOR GASKET	76712711		
MOTOR SUPPORT	01702701		
FAN MOTOR	15704102		
CENTRIFUGAL FAN	10312705		
CONNECTED BOARD ASSY OF EVAPORATOR	01074042		
FILTER SUB-ASSY	07210028		
DRAIN HOSE SUB-ASSY	05232702		
WATER TRAY ASSY	20182701		
ELECTRIC BASE PLATE	01412721		
DIVERSION CIRCLE	10372701		
ELECTRIC BOX ASSY	01399400006		
TRANSFORMER	4311023303		
TERMINAL BOARD	42010196		
ELECTRIC BOX COVER	20102702		
ELECTRIC BOX COVER SUB-ASSY1	20122054		
TEMPERATURE SENSOR	390001982G		
AMBIENT TEMPERATURE SENSOR	390001977		
ELECTRIC BOX COVER SUB-ASSY2	20122055		
ELECTRIC BOX COVER	20102702		
MAIN BOARD	30226340		
CAPACITOR CBB61	33010027		
EVAPORATOR ASSY	01029400012		
EVAPORATOR SUPPORT ASSY	01072703		
MAGNETIC RING	NONE		
WATER PUMP	43130324		
WATER PUMP ASSY	01332752		
PUMP SUPPORT	01329416		
WATER LEVEL SWITCH	45020216		
PUMP DRAINPIPE	05230026		
RIGHT SIDE PLATE ASSY	01302716		
REMOTE CONTROLLER	305100491		
PUMP COVER BOARD ASSY	01252713		
DISPLAY BOARD	30296317		